
REGULATOR HANDLE REMOVAL


id091200806300

1. Insert a tape-wrapped flathead screwdriver into the position shown in the figure.



am2zzw00007548

2. Move the tape-wrapped flathead screwdriver in the direction of the arrow shown in the figure and detach the clip from the regulator handle.
3. Remove the regulator handle.
4. Remove the cover.



am2zzw00007549