KEYLESS BEEPER


id091400109700

Purpose, Function

- Notifies the user that the lock/unlock operation of the advanced keyless entry system is completed, and warns if the system is operated incorrectly.

Construction/Operation

- A keyless beeper is located on the inside of the cowl grille.
- The keyless beeper operates based on the LF control unit signal. For details of the beeper operation, refer to the alert function operation in the [ADVANCED KEYLESS ENTRY SYSTEM]. (See ADVANCED KEYLESS ENTRY SYSTEM.)



am2zzn00002354

Fail-safe

- Not applicable

cardiagn.com