REAR DOOR LATCH SWITCH


id091400110800

Purpose, Function

- Turns on/off in conjunction with the latch lever rotation so that the rear door open/closed condition is output to the BCM.

Construction

- The switch is turned on/off by the rotation of the latch lever.



am2zzn00001671

Operation

Door open (unlatch) operation

- When the inner or outer handle is operated, the door opens, the latch lever is in an unlatched condition, and the rear door latch switch turns on according to the operation of the latch lever.

Door closed (latched) operation

1. When a door is closed, the rear door lock striker enters the latch lever groove.
2. When the door is further closed after the latch lever groove enters the rear door lock striker, the latch lever is pressed by the rear door lock striker and it rotates.
3. When the door is fully closed, the latch lever is in a latched condition, and the rear door latch switch turns off according to the operation of the latch lever.

Fail-safe

- Not applicable