
REMOTE TRANSMITTER

id091400111700

Purpose
- When the lock button/unlock button of the remote transmitter is pressed, ID data is sent to the keyless receiver.

Function
- When the remote transmitter sends ID data, the operation indicator light is turned on.

Construction
- The remote transmitter has a built-in operation indicator light.
- The remote transmitter has a built-in electronic communication device (transponder) and specific electronic codes (key ID number).
- In case the remote transmitter is inoperable due to battery depletion, the doors can be locked/unlocked using the auxiliary key.



am2zzn00001837

Operation
- When the remote transmitter button is pressed, ID data is sent to the keyless receiver.

Fail-safe
- Not applicable