START STOP UNIT CONFIGURATION (USING AS-BUILT DATA)

id091400112600

Note
- If the configuration is performed using As-Built data, the set value of the personalization function is reset to the initial value (condition when shipped from factory). Verify the set value with the customer and perform the personalization function setting after performing the configuration using As-Built data.
- If the ignition cannot be switched ON (engine off), switch it ON (engine off) using the forced ignition ON function of the M-MDS. (See FORCED IGNITION ON.)

1. Connect the M-MDS to the DLC-2.
2. After the vehicle is identified, select the following items from the initialization screen of the M-MDS.
    1. Select “Module Programming”.
3. Then, select items from the screen menu in the following order.
    1. Select “As-Built”.
    2. Select “SSU”.
4. Perform the configuration according to the directions on the screen.

Caution
- **When the configuration is performed, CAN communication between the start stop unit and control module connected to the CAN circuit is cut temporarily, and communication error DTCs may be detected. After performing the configuration, verify the DTCs for the control module connected to the CAN circuit and clear them if any are detected.**

5. Verify the DTCs for all of the control modules connected to the CAN circuit.
    - If any DTC is stored, clear it.
    - If the DTC is cleared, finish the procedure because the configuration has been completed normally.
    - If the DTC remains, perform troubleshooting according to the DTC.