TRUNK LID OPENER SWITCH

id091400113900

Purpose

- Transmits the trunk lid opener switch operation of the user to the BCM.

Function

- The trunk lid opener switch on signal is senT tothe BCM by operating the trunk lid opener switch.

Construction, Operation