FRONT DOOR LATCH AND LOCK ACTUATOR INSPECTION

id091400511200

- The following actuator and switches are integrated with the front door latch and lock actuator.
- From the actuator/switch name and operation in the following table, select the actuator or switch to be inspected, and perform the inspection following the inspection procedure described in the reference.

Actuator/Switch name	Operation	Reference
Front door lock actuator	Electrically switches the lock/unlock of the front doors.	(See FRONT DOOR LOCK ACTUATOR INSPECTION.)
Front door lock-link switch	Switch turns on/off in conjunction with the lock/unlock of the driver's door lock knob so that the lock/unlock condition is detected.	(See FRONT DOOR LOCK-LINK SWITCH INSPECTION.)
Front door latch switch	Switch turns on/off in conjunction with the latch lever rotation so that the front door open/closed condition is detected.	(See FRONT DOOR LATCH SWITCH INSPECTION.)
Front door key cylinder switch	Turns on/off in conjunction with the lock/unlock of the front door key cylinder so that the key cylinder operation condition is detected.	(See FRONT DOOR KEY CYLINDER SWITCH INSPECTION.)