REAR DOOR LATCH AND LOCK ACTUATOR INSPECTION

id091400511800

- The following actuator and switch are integrated with the rear door latch and lock actuator.
- From the actuator/switch name and operation in the following table, select the actuator or switch to be inspected, and perform the inspection following the inspection procedure described in the reference.

Actuator/Switch name	Operation	Reference
Rear door lock actuator	Electrically switches the lock/unlock of the rear doors.	(See REAR DOOR LOCK ACTUATOR INSPECTION.)
Rear door lock-link switch	Turns on/off in conjunction with the lock/unlock so that the lock/unlock condition is detected.	(See REAR DOOR LOCK-LINK SWITCH INSPECTION.)
Rear door latch switch	Turns on/off in conjunction with the latch lever operation so that the rear door open/closed condition is detected.	(See REAR DOOR LATCH SWITCH INSPECTION.)