LIFTGATE LATCH AND LOCK ACTUATOR INSPECTION

id091400517000

- The following actuator and switch are integrated with the liftgate latch and lock actuator.
- From the actuator/switch name and operation in the following table, select the actuator or switch to be inspected, and perform the inspection following the inspection procedure described in the reference.

Actuator/Switch name	Operation	Reference
Liftgate lock actuator	Electrically unlatches the liftgate based on the signal from the BCM.	(See LIFTGATE LOCK ACTUATOR INSPECTION.)
Liftgate latch switch	Turns on/off in conjunction with the latch lever rotation so that the liftgate open/closed condition is detected.	(See LIFTGATE LATCH SWITCH INSPECTION.)