
FUEL TANK SIDE COVER REMOVAL/INSTALLATION

id091600030000

1. Lift up the vehicle.
2. Remove the bolts and nuts.



adejjw00009449

3. Remove the fuel tank side cover.
4. Install in the reverse order of removal.