
RADIATOR GRILLE DISASSEMBLY/ASSEMBLY

id091600460100

1. Disassemble in the order indicated in the table.



am2zzw00008942

1	Ornament
2	Seal plate
3	Locator pin
4	Grille garnish (with grille garnish)
5	Radiator grille reinforcement

2. Assemble in the reverse order of disassembly.