
DASHBOARD UNDER COVER REMOVAL/INSTALLATION

id091700601100

1. With the end of the hook pressed out in the direction of arrow (1) shown in the figure, move the dashboard panel under cover in the direction of arrow (2) and detach the hooks and pins.

Caution

- **When detaching the hooks and pins, if the dashboard under cover is moved downward forcefully, the guide may be damaged.Be careful not to damage the guide when detaching the hooks and pins.**



am2zzw00007593

2. Move the dashboard under cover in the direction of arrow (3) shown in the figure and remove it while releasing the guide.
3. Install in the reverse order of removal.