
LIFTGATE UPPER TRIM REMOVAL/INSTALLATION

id091700605100

1. Hold the shaded area shown in the figure, pull the liftgate upper trim in the order of the arrows, detach clips A, B, and C from the liftgate and remove the liftgate upper trim.



am2zzw00007912

2. Install in the reverse order of removal.