
LIFTGATE LOWER TRIM REMOVAL/INSTALLATION

id091700605200

1. Remove the fasteners, then remove the liftgate lower trim.



am2zzw00007913

2. Install in the reverse order of removal.