
5. Pull the shock-absorbing pad in the direction of the arrow (3) and remove it while detaching guide.





(22)Adjust anchor cover (See FRONT SEAT BELT REMOVAL/INSTALLATION.)
(23)Upper anchor installation bolt on the seat belt (See FRONT SEAT BELT REMOVAL/INSTALLATION.)
(24)B-pillar upper trim (S

(25)C-pillar trim (See C-PILLAR TRIM REMOVAL/INSTALLATION.)
(26)Headliner (See HEADLINER REMOVAL/INSTALLATION.)

3. While holding the tabs of the shock-absorbing pad using pincers, pull the tabs in the direction of arrow (1) shown in the figure and detach the tabs from the side panel.

