FRONT FOG LIGHT BULB REMOVAL/INSTALLATION

id091800802300

1. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/ CONNECTION.)
2. Partially peel back front mudguard. (See MUDGUARD REMOVAL/INSTALLATION.)
3. Disconnect the connector.

Caution

- **If there is oil or dirt on the surface of the**