WIPER AND WASHER SWITCH REMOVAL/INSTALLATION

id091900800200

Note

- When removing the wiper and washer switch, it is necessary to turn the steering wheel. If the ignition is switched off with the driver's door closed, the steering wheel is locked. Perform Steps 1—3 to prevent the steering wheel from being locked.

IGNITION START STOP UNIT

