
REAR WASHER NOZZLE ADJUSTMENT

id091900802300


Caution

- **Inserting a flathead screwdriver into the rear washer nozzle hole and adjusting the nozzle angle with a strong force may damage the inside of the nozzle. Do not apply strong force and carefully adjust the windshield washer nozzle.**

1. Insert a flathead screwdriver into the rear washer nozzle hole and adjust the nozzle so that washer fluid is sprayed within the range shown in the figure.



am2zzw00011649



am2zzw00011650