
WIPER/WASHER SYSTEM LOCATION INDEX

id091900903000



am2zzw00011690

1	Windshield washer hose A (See WINDSHIELD WASHER HOSE REMOVAL/ INSTALLATION.)
2	Rear washer hose A (5HB) (See REAR WASHER HOSE REMOVAL/ INSTALLATION.)

3	Rear washer hose B (5HB) (See REAR WASHER HOSE REMOVAL/ INSTALLATION.)
4	Windshield washer hose B (See WINDSHIELD WASHER HOSE REMOVAL/ INSTALLATION.)
5	Windshield wiper arm and blade (See WINDSHIELD WIPER ARM AND BLADE REMOVAL/INSTALLATION.) (See WINDSHIELD WIPER ARM AND BLADE ADJUSTMENT.)
6	Windshield wiper motor and link (See WINDSHIELD WIPER MOTOR AND LINK REMOVAL/INSTALLATION.) (See WINDSHIELD WIPER MOTOR INSPECTION.)
7	Rain sensor (with auto wiper system) (See RAIN SENSOR REMOVAL/INSTALLATION.) (See RAIN SENSOR INITIALIZATION SETTING.) (See WIPER/WASHER SYSTEM PERSONALIZATION FEATURES SETTING PROCEDURE.)
8	Windshield washer nozzle (See WINDSHIELD WASHER NOZZLE REMOVAL/ INSTALLATION.) (See WINDSHIELD WASHER NOZZLE ADJUSTMENT.)
9	Headlight cleaner actuator (with headlight cleaner system) (See HEADLIGHT CLEANER ACTUATOR REMOVAL/INSTALLATION.)
10	Headlight cleaner hose (with headlight cleaner system) (See HEADLIGHT CLEANER HOSE REMOVAL/ INSTALLATION.)
11	Headlight cleaner cover (with headlight cleaner system) (See HEADLIGHT CLEANER COVER REMOVAL/ INSTALLATION.)
12	Washer tank (See WASHER TANK REMOVAL/INSTALLATION.)
13	Washer motor (See WASHER MOTOR REMOVAL/ INSTALLATION.) (See WASHER MOTOR INSPECTION.)
14	Headlight cleaner motor (with headlight cleaner system) (See HEADLIGHT CLEANER MOTOR REMOVAL/ INSTALLATION.) (See HEADLIGHT CLEANER MOTOR INSPECTION.)
15	Washer fluid-level sensor (with headlight cleaner system) (See WASHER FLUID-LEVEL SENSOR REMOVAL/ INSTALLATION.) (See WASHER FLUID-LEVEL SENSOR INSPECTION.)
16	Wiper and washer switch (See WIPER AND WASHER SWITCH REMOVAL/ INSTALLATION.) (See WIPER AND WASHER SWITCH INSPECTION.)
17	Rear wiper motor (5HB) (See REAR WIPER MOTOR REMOVAL/ INSTALLATION.) (See REAR WIPER MOTOR INSPECTION.)
18	Rear wiper arm and blade (5HB) (See REAR WIPER ARM AND BLADE REMOVAL/ INSTALLATION.) (See REAR WIPER ARM AND BLADE ADJUSTMENT.)
19	Rear washer nozzle (5HB) (See REAR WASHER NOZZLE REMOVAL/ INSTALLATION.) (See REAR WASHER NOZZLE ADJUSTMENT.)
20	Rear washer hose D (5HB) (See REAR WASHER HOSE REMOVAL/ INSTALLATION.)
21	Rear washer hose C (5HB) (See REAR WASHER HOSE REMOVAL/ INSTALLATION.)

cardiagn.com