
CONNECTIVITY MASTER UNIT (CMU) DISASSEMBLY/ASSEMBLY

id092000031600

1. Disassemble in the order indicated in the table.




adejjw00008806

1	Screw A
2	Bracket A
3	Screw B
4	Bracket B
5	Short-cord (See Short-cord Assembly Note.)
6	Connectivity master unit (CMU)

2. Assemble in the reverse order of disassembly.

Short-cord Assembly Note

- When assembling the short-cord, press it into the groove of the CMU.



am2zzw00008316