
DVD/CD PLAYER INSTALLATION

id092000035300

1. Connect the connector.



am2zzw00009886

2. Install the DVD/CD player.
3. Shift the selector lever back to the P position. (ATX)
4. Connect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION.)