STEERING SWITCH [WITHOUT CENTER DISPLAY]

id0920z9010500

Purpose, Function


- Operation of the entertainment system and changing of the trip computer system display are possible without a change in driving posture.

Construction

- The steering switch is located on the spoke of the steering wheel.
- The resistance is built into each switch.

Without Bluetooth® unit


- The steering switch consists of a volume adjustment (+) or (-) switch, cue/automatic band selector (up) or (down) switch, INFO button, up switch, down switch, and mute button.



am2zzn00003506

With Bluetooth® unit

- The steering switch consists of a volume adjustment (+) or (-) switch, cue/automatic band selector (up) or (down) switch, INFO button, up switch, down switch, TALK button, PICK-UP button, and HANG-UP button.



am2zzn00003507

Operation

Switch name	Operation
Volume adjustment switch	Audio volume can be adjusted.
Cue/Automatic band selector switch	Cue of CD tracks and selection of radio band are possible.
Mute button (Without Bluetooth® unit)	Audio volume can be muted. Pressing again after muting returns to previous volume level.
INFO button	Instrument cluster display can be changed. Refer to TRIP COMPUTER INFORMATION SYSTEM for display content. (See TRIP COMPUTER INFORMATION SYSTEM.)
Up/down switch	Instrument cluster display can be changed. Refer to TRIP COMPUTER INFORMATION SYSTEM for display content. (See TRIP COMPUTER INFORMATION SYSTEM.)
TALK button (With Bluetooth® unit)	Launches the voice recognition function.
Pick-up button (With Bluetooth® unit)	Receives a phone call.
Hang-up button (With Bluetooth® unit)	Hangs up a phone call.

Fail-safe

- Not applicable