STEERING SWITCH [WITH CENTER DISPLAY]


id0920zz010500

Purpose, Function

- Operation of the entertainment system and changing of the trip computer system display are possible without a change in driving posture.

Construction

- The steering switch is located on the spoke of the steering wheel.
- The resistance is built into each switch.
- The steering switch consists of a volume adjustment switch (+) or (-), cue/automatic band selector switch (up) or (down), INFO button, up/down switch, talk button, pick-up button and hang-up button.



am2zzn00003515

Operation

Switch name	Operation
Volume adjustment switch	Audio volume can be adjusted.
Cue/Automatic band selector switch	Cues the CD or switches radio stations.
INFO button	Trip computer system display can be changed. For the display content, refer to the TRIP COMPUTER SYSTEM. (See TRIP COMPUTER INFORMATION SYSTEM.)
Up/down switch	Trip computer system display can be changed. For the display content, refer to the TRIP COMPUTER SYSTEM. (See TRIP COMPUTER INFORMATION SYSTEM.)
Talk button	Initiates voice recognition mode.
Pick-up button	**During incoming call** • Receives phone call **Other than during incoming call** • Switches display of center display to call history screen.
Hang-up button	Hangs up the phone call.

Fail-safe

- Not applicable