AM/FM ANTENNA AMPLIFIER [WITH CENTER DISPLAY]

id0920zz014200

Purpose, Function

- Amplifies the electric signal from the glass antenna and sends it to the tuner and amp unit (TAU).

Construction

- The AM/FM antenna amplifier is located in the rear header.