
RELAY LOCATION

id092100800600

SKYACTIV-G 1.3, SKYACTIV-G 1.5




am2zzw00008712

1	IG1 relay
2	A/C relay
3	Front fog light relay
4	Headlight cleaner relay
5	Theft-deterrent relay
6	Brake light relay
7	Ignition relay (ACC_STAB)
8	Horn relay
9	Electric at oil pump relay
10	Wiper INT relay
11	Wiper HI relay
12	Starter relay

13	Electric variable valve timing relay
14	ACC relay
15	Rear window defogger relay
16	Ignition relay (IG1_STAB)
17	Blower relay
18	Fuel pump relay
19	Fuel injector relay
20	Main relay
21	Cooling fan relay No.2
22	Cooling fan relay No.1

SKYACTIV-D 1.5



am2zzw00008713

1	IG1 relay
2	A/C relay
3	Front fog light relay
4	Headlight cleaner relay
5	Theft-deterrent relay
6	Brake light relay
7	Ignition relay (ACC_STAB)
8	Horn relay
9	Electric at oil pump relay
10	Wiper INT relay
11	Wiper HI relay

12	Starter relay
13	ACC relay
14	Rear window defogger relay
15	Ignition relay (IG1_STAB)
16	Blower relay
17	Blow-by heater relay
18	Check connector
19	Main relay
20	Cooling fan relay