POWER SYSTEMS

id092100960000

Outline

- The power systems supply electrical power stored in the battery to the vehicle's electrical devices as their power supply.
- Three types of electric power supply are used for the systems and parts depending on their usage.
  - — Power is directly supplied from the battery
  - — Power is supplied when ignition is switched ON (engine off)
  - — Power is supplied when ignition is switched ON (engine on)

Specification

SKYACTIV-G 1.3, SKYACTIV-G 1.5


Component parts	Specification	
Relay and fuse block	Wiring harness-integrated type	
Fuse block	Wiring harness-integrated type	
Main fuse	DCDC fuse capacity	50 A
	EPAS fuse capacity	60 A
	MAIN fuse capacity	200 A
	STR fuse capacity	200 A
Accessory socket	Rated voltage	DC 12 V
	Rated load	10 A

SKYACTIV-D 1.5

Component parts	Specification	
Relay and fuse block	Wiring harness-integrated type	
Fuse block	Wiring harness-integrated type	
Main fuse	DCDC fuse capacity (With i-ELOOP)	200 A
	GLOW fuse capacity	80 A
	EPAS fuse capacity	60 A
	PTC fuse capacity	100 A
	MAIN fuse capacity	200 A
	STR fuse capacity	250 A
Accessory socket	Rated voltage	DC 12 V
	Rated load	10 A

cardiagn.com

Structural View



am2zzn00002691