PARKING SENSOR CONTROL MODULE

id092200024400

Purpose

- The parking sensor control module activates the parking sensor buzzer based on information from the ultrasonic sensor.


Function

- The parking sensor control module controls the parking sensor system based on the following signals.

Signal name	Sending module/part name	Communication method
Vehicle speed signal	Instrument cluster	Hard wire
Back-up light signal	Electrical supply unit (ESU)	

Construction

- The parking sensor control module is located inside the dashboard.



am2zzn00002896

Operation

- For the parking sensor control module operation, refer to the [PARKING SENSOR SYSTEM]. (See PARKING SENSOR SYSTEM.)

Fail-safe

- Not applicable