
FORWARD SENSING CAMERA (FSC) SHORT-CORD REMOVAL/INSTALLATION

id092200030300

1. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/ CONNECTION.)
2. Remove the sensor cover. (See SENSOR COVER REMOVAL/INSTALLATION.)
3. Remove the rearview mirror. (See REARVIEW MIRROR REMOVAL/INSTALLATION.)
4. Disconnect the connector.



ac5wzw00000100

5. Pull out the FSC short-cord in the direction of arrow (2) shown in the figure while pressing the clip in the direction of arrow (1) shown in the figure, detach the clip and base, and remove the FSC short-cord.
6. Install in the reverse order of removal.

cardiagn.com