FORWARD SENSING CAMERA (FSC) CONFIGURATION (USING AS-BUILT DATA)

id092200032300

Caution

- **When the configuration is performed, CAN communication between the FSC and control module connected to the CAN circuit is cut temporarily, and communication error DTCs may be detected. After performing the configuration, verify the DTCs for the control module connected to the CAN circuit and clear it if any DTC is detected.**

Note

- If the configuration is performed using As-Built data, the set value of the personalization function is reset to the initial value (condition when shipped from factory). Verify the set value with the customer and perform the personalization function setting after performing the configuration using As-Built data.

1. Connect the M-MDS to the DLC-2.
2. After vehicle identification, select the following from the M-MDS initialization screen.
    1. “Module programming”
3. Then, select the following from the screen menu.
    1. “As-Built”
    2. “FSC”
4. Perform As-Built following the instructions on the screen.
5. Verify the DTCs for all of the control modules connected to the CAN circuit.
    - If any DTC is stored, clear it.
    - If the DTC is cleared, finish the procedure because the configuration has been completed normally.
    - If the DTC remains, perform troubleshooting according to the DTC.