
BODY SEALING [WATER-PROOF AND RUST PREVENTIVE]

id098009739800

- Sealant is applied to the parts where the panels meet and to the hemmed parts of the door panel and bonnet panel to provide water proofing and rust proofing.

4SD/5HB




am2zzb00000644




am2zzb00000645

4SD



am2zzb00000647


REAR BODY



:BODY SEALANT
:BODY SEALANT(ROOM)

am2zzb00000648


UNDER BODY



:BODY SEALANT

am2zzb00000656


BONNET




DOOR

FRONT DOOR HINGE








REAR DOOR HINGE




TRUNK LID



: BODY SEALANT

am2zzb00000657


ROOM (REAR-SIDE)



: BODY SEALANT
: BODY SEALANT (ROOM)


am2zzb00000646

REAR BODY




:BODY SEALANT
:BODY SEALANT (ROOM)

am2zzb00000627



am2zzb00000628


BONNET




DOOR

FRONT DOOR HINGE








REAR DOOR HINGE



LIFTGATE



LIFTGATE HINGE



BODY SEALANT

am2zzb00000629