ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
P00 DIAGNOSIS				
DTC READING BY DIAGNOSTIC TOOL The labor operation for DIAGNOSTIC TOOLS usage (P9999*–*–*) can be applied only when the diagnosis requires the NGS/WDS/PDS/IDS tester to read the Diagnostic Trouble Code for ABS components.		P9999XDX	0.2	
P01 FRONT BRAKE				
CALIPER ASSEMBLY, OH	Rear drum brake type,One side	P0101AHX	0.7	◆Caliper assembly (P0101), R&R◆Brake line (A0120), Air bleed
CALIPER ASSEMBLY, OH	Rear drum brake type,Both sides	P0101BHX	0.9	◆Caliper assembly (P0101), R&R◆Brake line (A0120), Air bleed
CALIPER ASSEMBLY, OH	Rear disc brake type,One side	P0101CHX	1.2	◆Caliper assembly (P0101), R&R◆Brake line (A0120), Air bleed
CALIPER ASSEMBLY, OH	Rear disc brake type,Both sides	P0101DHX	1.5	◆Caliper assembly (P0101), R&R◆Brake line (A0120), Air bleed
CALIPER ASSEMBLY, R&R	Rear drum brake type,One side	P0101ARX	0.5	◆Brake line (A0120), Air bleed
CALIPER ASSEMBLY, R&R	Rear drum brake type,Both sides	P0101BRX	0.7	◆Brake line (A0120), Air bleed
CALIPER ASSEMBLY, R&R	Rear disc brake type,One side	P0101CRX	1.1	◆Brake line (A0120), Air bleed
CALIPER ASSEMBLY, R&R	Rear disc brake type,Both sides	P0101DRX	1.2	◆Brake line (A0120), Air bleed
DISC PLATE, R&R	One side	P0102ARX	0.3	◆Caliper assembly (P0101), D&C
DISC PLATE, R&R	Both sides	P0102BRX	0.4	◆Caliper assembly (P0101), D&C
DUST PLATE, R&R	One side	P0103ARX	0.7	◆Caliper assembly (P0101), D&C◆Front wheel hub (M0203), R&R
DUST PLATE, R&R	Both sides	P0103BRX	1.1	◆Caliper assembly (P0101), D&C◆Front wheel hub (M0203), R&R
PAD, R&R	One side	P0104ARX	0.3	◆Caliper assembly (P0101), D&C
PAD, R&R	Both sides	P0104BRX	0.4	◆Caliper assembly (P0101), D&C
PAD ATTACHMENT, R&R	One side	P0105ARX	0.3	
PAD ATTACHMENT, R&R	Both sides	P0105BRX	0.4	

Carsdiagn.com

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
SEAL KIT, R&R	Rear drum brake type,One side	P0106ARX	0.6	◆Caliper assembly (P0101), R&R◆Brake line (A0120), Air bleed
SEAL KIT, R&R	Rear drum brake type,Both sides	P0106BRX	0.8	◆Caliper assembly (P0101), R&R◆Brake line (A0120), Air bleed
SEAL KIT, R&R	Rear disc brake type,One side	P0106CRX	1.1	◆Caliper assembly (P0101), R&R◆Brake line (A0120), Air bleed
SEAL KIT, R&R	Rear disc brake type,Both sides	P0106DRX	1.3	◆Caliper assembly (P0101), R&R◆Brake line (A0120), Air bleed
DISC PLATE, MACHINE	One side	P0113AMX	Max 0.6	◆Caliper assembly (P0101), D&C
DISC PLATE, MACHINE	Both sides	P0113BMX	Max 1.0	◆Caliper assembly (P0101), D&C
P02 REAR BRAKE				
BRAKE DRUM, R&R	One side	P0201ARX	0.4	◆Brake, Adjust
BRAKE DRUM, R&R	Both sides	P0201BRX	0.5	◆Brake, Adjust
RETURN SPRING, R&R	One side	P0202ARX	0.3	
RETURN SPRING, R&R	Both sides	P0202BRX	0.4	
BRAKE SHOE GUIDE PIN AND/OR CLIP SPRING, R&R	One side	P0203ARX	0.3	
BRAKE SHOE GUIDE PIN AND/OR CLIP SPRING, R&R	Both sides	P0203BRX	0.4	
BRAKE SHOE AND/OR ADJUSTER, R&R	One side	P0204ARX	0.5	◆Brake drum (P0201), R&R◆Brake, Adjust
BRAKE SHOE AND/OR ADJUSTER, R&R	Both sides	P0204BRX	0.6	◆Brake drum (P0201), R&R◆Brake, Adjust
WHEEL CYLINDER ASSEMBLY, OH	One side	P0206AHX	0.8	◆Wheel cylinder assembly (P0206), R&R◆Brake line (A0120), Air bleed◆Brake, Adjust
WHEEL CYLINDER ASSEMBLY, OH	Both sides	P0206BHX	1.1	◆Wheel cylinder assembly (P0206), R&R◆Brake line (A0120), Air bleed◆Brake, Adjust
WHEEL CYLINDER ASSEMBLY, R&R	One side	P0206ARX	0.7	◆Brake drum (P0201), R&R◆Brake line (A0120), Air bleed◆Brake, Adjust
WHEEL CYLINDER ASSEMBLY, R&R	Both sides	P0206BRX	0.9	◆Brake drum (P0201), R&R◆Brake line (A0120), Air bleed◆Brake, Adjust

cardiagn.com

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
CALIPER ASSEMBLY, R&R	One side	P0207ARX	1.0	◆Brake line (A0120), Air bleed
CALIPER ASSEMBLY, R&R	Both sides	P0207BRX	1.1	◆Brake line (A0120), Air bleed
DISC PLATE, R&R	One side	P0208ARX	0.4	◆Caliper assembly (P0207), D&C
DISC PLATE, R&R	Both sides	P0208BRX	0.6	◆Caliper assembly (P0207), D&C
PAD, R&R	One side	P0209ARX	0.5	◆Caliper assembly (P0207), D&C
PAD, R&R	Both sides	P0209BRX	0.7	◆Caliper assembly (P0207), D&C
PAD ATTACHMENT, R&R	One side	P0210ARX	0.5	
PAD ATTACHMENT, R&R	Both sides	P0210BRX	0.7	
BRAKE DRUM BACK PLATE, R&R	One side	P0211ARX	0.9	◆Brake shoe and/or adjuster (P0204), R&R ◆Wheel cylinder assembly (P0206), R&R◆ Rear wheel hub (M0314), R&R◆Brake line (A0120), Air bleed◆Brake, Adjust
BRAKE DRUM BACK PLATE, R&R	Both sides	P0211BRX	1.3	◆Brake shoe and/or adjuster (P0204), R&R ◆Wheel cylinder assembly (P0206), R&R◆ Rear wheel hub (M0314), R&R◆Brake line (A0120), Air bleed◆Brake, Adjust
BACK PLATE, R&R	One side	P0212ARX	0.4	◆Rear wheel hub (M0314), R&R
BACK PLATE, R&R	Both sides	P0212BRX	0.7	◆Rear wheel hub (M0314), R&R
DISC PLATE, MACHINE	One side	P0214AMX	Max 0.7	◆Caliper assembly (P0207), D&C
DISC PLATE, MACHINE	Both sides	P0214BMX	Max 1.1	◆Caliper assembly (P0207), D&C
BRAKE DRUM, MACHINE	One side	P0215AMX	Max 0.5	◆Brake drum (P0201), R&R◆Brake, Adjust
BRAKE DRUM, MACHINE	Both sides	P0215BMX	Max 0.6	◆Brake drum (P0201), R&R◆Brake, Adjust
P03 BRAKE PEDAL				
BRAKE PEDAL AND/OR BUSH, R&R	LHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Without i-stop,PCM cover with standard bolts	P0301ARX	0.8	
BRAKE PEDAL AND/OR BUSH, R&R	***[LHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Without i-stop,PCM cover with shear-off bolts,Without i-ELOOP system]/[LHD,SKYACTIV-G 1.5,Without Coolant Control Valve,With i-stop]/[LHD,SKYACTIV-G 1.5,With Coolant Control Valve,Without Mazda M Hybrid]***	P0301BRX	0.9	

cardiagn.com

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
BRAKE PEDAL AND/OR BUSH, R&R	***LHD,SKYACTIV-G 1.5,With Coolant Control Valve,With Mazda M Hybrid***	***P0301HRX***	***0.9***	
BRAKE PEDAL AND/OR BUSH, R&R	LHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Without i-stop,PCM cover with shear-off bolts,With i-ELOOP system	P0301ERX	1.1	
BRAKE PEDAL AND/OR BUSH, R&R	LHD,SKYACTIV-D 1.5,Without i-ELOOP system	P0301FRX	0.8	
BRAKE PEDAL AND/OR BUSH, R&R	LHD,SKYACTIV-D 1.5,With i-ELOOP system	P0301GRX	0.9	
BRAKE PEDAL AND/OR BUSH, R&R	RHD,Without i-stop	P0301CRX	0.5	
BRAKE PEDAL AND/OR BUSH, R&R	RHD,With i-stop	P0301DRX	0.6	
BRAKE SWITCH, R&R		P0302XRX	0.2	
P04 POWER BRAKE & BRAKE PIPING				
MASTER CYLINDER ASSEMBLY, R&R	LHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear drum brake type,Without i-stop,PCM cover with standard bolts	P0401ARX	0.8	◆Brake line (A0120), Air bleed
MASTER CYLINDER ASSEMBLY, R&R	[LHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear drum brake type,Without i-stop,PCM cover with shear-off bolts,Without i-ELOOP system]/[LHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear drum brake type,With i-stop]/[LHD,SKYACTIV-G 1.5,With Coolant Control Valve,Rear drum brake type]	P0401BRX	0.9	◆Brake line (A0120), Air bleed
MASTER CYLINDER ASSEMBLY, R&R	LHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear drum brake type,Without i-stop,PCM cover with shear-off bolts,With i-ELOOP system	P0401HRX	1.0	◆Brake line (A0120), Air bleed
MASTER CYLINDER ASSEMBLY, R&R	LHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear disc brake type,Without i-stop,PCM cover with standard bolts	P0401JRX	1.3	◆Brake line (A0120), Air bleed

Carmagn.com

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
MASTER CYLINDER ASSEMBLY, R&R	[LHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear disc brake type,Without i-stop,PCM cover with shear-off bolts]/[LHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear disc brake type,With i-stop]/[LHD,SKYACTIV-G 1.5,With Coolant Control Valve,Rear disc brake type]	P0401KRX	1.4	◆Brake line (A0120), Air bleed
MASTER CYLINDER ASSEMBLY, R&R	LHD,SKYACTIV-D 1.5,Rear drum brake type	P0401LRX	0.9	◆Brake line (A0120), Air bleed
MASTER CYLINDER ASSEMBLY, R&R	LHD,SKYACTIV-D 1.5,Rear disc brake type	P0401MRX	1.4	◆Brake line (A0120), Air bleed
MASTER CYLINDER ASSEMBLY, R&R	RHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear drum brake type,Without i-stop	P0401CRX	0.7	◆Brake line (A0120), Air bleed
MASTER CYLINDER ASSEMBLY, R&R	[RHD,SKYACTIV-G 1.3,Rear drum brake type]/[RHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear drum brake type,With i-stop]/[RHD,SKYACTIV-G 1.5,With Coolant Control Valve]	P0401DRX	0.8	◆Brake line (A0120), Air bleed
MASTER CYLINDER ASSEMBLY, R&R	[RHD,SKYACTIV-G 1.3,Rear disc brake type]/[RHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear disc brake type]	P0401ERX	1.3	◆Brake line (A0120), Air bleed
MASTER CYLINDER ASSEMBLY, R&R	RHD,SKYACTIV-D 1.5,Rear drum brake type	P0401FRX	1.1	◆Brake line (A0120), Air bleed
MASTER CYLINDER ASSEMBLY, R&R	RHD,SKYACTIV-D 1.5,Rear disc brake type	P0401GRX	1.6	◆Brake line (A0120), Air bleed
POWER BRAKE UNIT, R&R	LHD,SKYACTIV-G 1.5,With Coolant Control Valve,Rear drum brake type,Without i-stop	P0402PRX	1.5	◆Master cylinder assembly (P0401), R&R◆ Brake line (A0120), Air bleed

carsdiagn.com

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
POWER BRAKE UNIT, R&R	[LHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear drum brake type,Without i-stop,PCM cover with standard bolts]/[LHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear drum brake type,With i-stop]/[LHD,SKYACTIV-G 1.5,With Coolant Control Valve,Rear drum brake type,With i-stop]	P0402ARX	1.4	◆Master cylinder assembly (P0401), R&R◆ Brake line (A0120), Air bleed
POWER BRAKE UNIT, R&R	LHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear drum brake type,Without i-stop,PCM cover with shear-off bolts,Without i-ELOOP system	P0402BRX	1.5	◆Master cylinder assembly (P0401), R&R◆ Brake line (A0120), Air bleed
POWER BRAKE UNIT, R&R	LHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear drum brake type,Without i-stop,PCM cover with shear-off bolts,With i-ELOOP system	P0402JRX	1.6	◆Master cylinder assembly (P0401), R&R◆ Brake line (A0120), Air bleed
POWER BRAKE UNIT, R&R	LHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear disc brake type,Without i-stop,PCM cover with standard bolts	P0402KRX	1.9	◆Master cylinder assembly (P0401), R&R◆ Brake line (A0120), Air bleed
POWER BRAKE UNIT, R&R	[LHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear disc brake type,Without i-stop,PCM cover with shear-off bolts]/[LHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear disc brake type,With i-stop]/[LHD,SKYACTIV-G 1.5,With Coolant Control Valve,Rear disc brake type]	P0402LRX	2.0	◆Master cylinder assembly (P0401), R&R◆ Brake line (A0120), Air bleed
POWER BRAKE UNIT, R&R	LHD,SKYACTIV-D 1.5,Rear drum brake type	P0402MRX	1.5	◆Master cylinder assembly (P0401), R&R◆ Brake line (A0120), Air bleed
POWER BRAKE UNIT, R&R	LHD,SKYACTIV-D 1.5,Rear disc brake type	P0402NRX	2.0	◆Master cylinder assembly (P0401), R&R◆ Brake line (A0120), Air bleed

carwagn.com

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
POWER BRAKE UNIT, R&R	RHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear drum brake type,Without i-stop	P0402CRX	1.4	◆Master cylinder assembly (P0401), R&R◆ Brake line (A0120), Air bleed
POWER BRAKE UNIT, R&R	[RHD,SKYACTIV-G 1.3,Rear drum brake type]/[RHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear drum brake type,With i-stop]/[RHD,SKYACTIV-G 1.5,With Coolant Control Valve]	P0402DRX	1.5	◆Master cylinder assembly (P0401), R&R◆ Brake line (A0120), Air bleed
POWER BRAKE UNIT, R&R	[RHD,SKYACTIV-G 1.3,Rear disc brake type]/[RHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear disc brake type,Without i-stop]	P0402ERX	2.0	◆Master cylinder assembly (P0401), R&R◆ Brake line (A0120), Air bleed
POWER BRAKE UNIT, R&R	RHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear disc brake type,With i-stop	P0402FRX	2.1	◆Master cylinder assembly (P0401), R&R◆ Brake line (A0120), Air bleed
POWER BRAKE UNIT, R&R	RHD,SKYACTIV-D 1.5,Rear drum brake type	P0402GRX	1.8	◆Master cylinder assembly (P0401), R&R◆ Brake line (A0120), Air bleed
POWER BRAKE UNIT, R&R	RHD,SKYACTIV-D 1.5,Rear disc brake type	P0402HRX	2.3	◆Master cylinder assembly (P0401), R&R◆ Brake line (A0120), Air bleed
VACUUM PUMP ASSEMBLY, R&R	***SKYACTIV-G 1.5,With Coolant Control Valve,Without i-stop,PCM cover with shear-off bolts***	P0407FRX	0.6	
VACUUM PUMP ASSEMBLY, R&R	***[SKYACTIV-G 1.3]/[SKYACTIV-G 1.5,Without Coolant Control Valve,Without i-stop,PCM cover with standard bolts]/[SKYACTIV-G 1.5,Without Coolant Control Valve,With i-stop,PCM cover with standard bolts]/[SKYACTIV-G 1.5,With Coolant Control Valve,With i-stop,PCM cover with standard bolts,Without i-ELOOP system]***	P0407ARX	0.5	

Cardiagn.com

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
VACUUM PUMP ASSEMBLY, R&R	***SKYACTIV-G 1.5,With Coolant Control Valve,Without i-stop,PCM cover with standard bolts***	***P0407JRX***	***0.5***	
VACUUM PUMP ASSEMBLY, R&R	[SKYACTIV-G 1.5,Without Coolant Control Valve,Without i-stop,PCM cover with shear-off bolts,Without i-ELOOP system]/[SKYACTIV-G 1.5,Without Coolant Control Valve,With i-stop,PCM cover with shear-off bolts,Without i-ELOOP system]/[SKYACTIV-G 1.5,With Coolant Control Valve,With i-stop,PCM cover with shear-off bolts,Without i-ELOOP system]	P0407BRX	0.6	
VACUUM PUMP ASSEMBLY, R&R	***SKYACTIV-G 1.5,With Coolant Control Valve,With i-stop,PCM cover with standard bolts,With i-ELOOP system***	***P0407HRX***	***0.6***	
VACUUM PUMP ASSEMBLY, R&R	SKYACTIV-G 1.5,Without Coolant Control Valve,Without i-stop,PCM cover with shear-off bolts,With i-ELOOP system	P0407DRX	0.7	
VACUUM PUMP ASSEMBLY, R&R	***[SKYACTIV-G 1.5,Without Coolant Control Valve,With i-stop,PCM cover with shear-off bolts,With i-ELOOP system]/[SKYACTIV-G 1.5,With Coolant Control Valve,With i-stop,PCM cover with shear-off bolts,With i-ELOOP system]***	P0407ERX	0.8	
VACUUM PUMP ASSEMBLY, R&R	***SKYACTIV-G 1.5,With Coolant Control Valve,With i-stop,PCM cover with shear-off bolts,With Mazda M Hybrid***	***P0407GRX***	***0.8***	
VACUUM PUMP ASSEMBLY, R&R	***SKYACTIV-G 1.5,With Coolant Control Valve,With i-stop,PCM cover with standard bolts,With Mazda M Hybrid***	***P0407KRX***	***0.6***	
VACUUM PUMP ASSEMBLY, R&R	SKYACTIV-D 1.5	P0407CRX	***0.9***	

mazdaesa.com

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
FRONT BRAKE HOSE, R&R	Rear drum brake type,One side	P0408ARX	0.5	◆Brake line (A0120), Air bleed
FRONT BRAKE HOSE, R&R	Rear drum brake type,Both sides	P0408BRX	0.6	◆Brake line (A0120), Air bleed
FRONT BRAKE HOSE, R&R	Rear disc brake type,One side	P0408CRX	1.1	◆Brake line (A0120), Air bleed
FRONT BRAKE HOSE, R&R	Rear disc brake type,Both sides	P0408DRX	1.2	◆Brake line (A0120), Air bleed
REAR BRAKE HOSE, R&R	Rear drum brake type,One side	P0409ARX	0.5	◆Brake line (A0120), Air bleed
REAR BRAKE HOSE, R&R	Rear drum brake type,Both sides	P0409BRX	0.6	◆Brake line (A0120), Air bleed
REAR BRAKE HOSE, R&R	Rear disc brake type,One side	P0409CRX	1.0	◆Brake line (A0120), Air bleed
REAR BRAKE HOSE, R&R	Rear disc brake type,Both sides	P0409DRX	1.0	◆Brake line (A0120), Air bleed
P05 ANTILOCK BRAKE SYSTEM				
ABS FRONT SENSOR, R&R	One side,Without i-stop	P0501ARX	0.3	
ABS FRONT SENSOR, R&R	One side,With i-stop	P0501BRX	0.4	
ABS FRONT SENSOR, R&R	Both sides	P0501CRX	0.5	
ABS HYDRAULIC UNIT, R&R	[LHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear drum brake type,Without i-stop]/[LHD,SKYACTIV-G 1.5,With Coolant Control Valve,Rear drum brake type,Without i-stop]	P0502ARX	1.1	◆Brake line (A0120), Air bleed
ABS HYDRAULIC UNIT, R&R	[LHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear drum brake type,With i-stop]/[LHD,SKYACTIV-G 1.5,With Coolant Control Valve,Rear drum brake type,With i-stop]	P0502BRX	1.2	◆Brake line (A0120), Air bleed
ABS HYDRAULIC UNIT, R&R	[LHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear disc brake type,Without i-stop]/[LHD,SKYACTIV-G 1.5,With Coolant Control Valve,Rear disc brake type]	P0502LRX	1.7	◆Brake line (A0120), Air bleed
ABS HYDRAULIC UNIT, R&R	LHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear disc brake type,With i-stop	P0502MRX	1.8	◆Brake line (A0120), Air bleed
ABS HYDRAULIC UNIT, R&R	LHD,SKYACTIV-D 1.5,Rear drum brake type	P0502NRX	1.5	◆Brake line (A0120), Air bleed
ABS HYDRAULIC UNIT, R&R	LHD,SKYACTIV-D 1.5,Rear disc brake type	P0502PRX	2.0	◆Brake line (A0120), Air bleed

carmanuals.com

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
ABS HYDRAULIC UNIT, R&R	RHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear drum brake type,Without i-stop	P0502CRX	1.2	◆Brake line (A0120), Air bleed
ABS HYDRAULIC UNIT, R&R	[RHD,SKYACTIV-G 1.3,Rear drum brake type]/[RHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear drum brake type,With i-stop,PCM cover with standard bolts]/[RHD,SKYACTIV-G 1.5,With Coolant Control Valve,PCM cover with standard bolts]	P0502DRX	1.3	◆Brake line (A0120), Air bleed
ABS HYDRAULIC UNIT, R&R	[RHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear drum brake type,With i-stop,PCM cover with shear-off bolts,Without i-ELOOP system]/[RHD,SKYACTIV-G 1.5,With Coolant Control Valve,PCM cover with shear-off bolts,Without i-ELOOP system]	P0502ERX	1.4	◆Brake line (A0120), Air bleed
ABS HYDRAULIC UNIT, R&R	[RHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear drum brake type,With i-stop,PCM cover with shear-off bolts,With i-ELOOP system]/[RHD,SKYACTIV-G 1.5,With Coolant Control Valve,PCM cover with shear-off bolts,With i-ELOOP system]	P0502QRX	1.6	◆Brake line (A0120), Air bleed
ABS HYDRAULIC UNIT, R&R	RHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear disc brake type,Without i-stop	P0502FRX	1.8	◆Brake line (A0120), Air bleed
ABS HYDRAULIC UNIT, R&R	[RHD,SKYACTIV-G 1.3,Rear disc brake type]/[RHD,SKYACTIV-G 1.5,Without Coolant Control Valve,Rear disc brake type,With i-stop]	P0502GRX	1.9	◆Brake line (A0120), Air bleed
ABS HYDRAULIC UNIT, R&R	RHD,SKYACTIV-D 1.5,Rear drum brake type,Without i-ELOOP system	P0502HRX	1.2	◆Brake line (A0120), Air bleed
ABS HYDRAULIC UNIT, R&R	RHD,SKYACTIV-D 1.5,Rear drum brake type,With i-ELOOP system	P0502JRX	1.3	◆Brake line (A0120), Air bleed

carsign.com

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
ABS HYDRAULIC UNIT, R&R	RHD,SKYACTIV-D 1.5,Rear disc brake type	P0502KRX	1.8	◆Brake line (A0120), Air bleed
ABS REAR SENSOR, R&R	5HB,One side,Without i-stop	P0504ARX	0.5	◆Trunk side trim (S1707), R&R
ABS REAR SENSOR, R&R	5HB,One side,With i-stop	P0504BRX	0.6	◆Trunk side trim (S1707), R&R
ABS REAR SENSOR, R&R	5HB,Both sides,Without i-stop	P0504CRX	0.7	◆Trunk side trim (S1707), R&R
ABS REAR SENSOR, R&R	5HB,Both sides,With i-stop	P0504DRX	0.8	◆Trunk side trim (S1707), R&R
ABS REAR SENSOR, R&R	4SD,One side,Without i-stop	P0504ERX	0.4	◆Tire house trim, R&R
ABS REAR SENSOR, R&R	4SD,One side,With i-stop	P0504FRX	0.5	◆Tire house trim, R&R
ABS REAR SENSOR, R&R	4SD,Both sides,Without i-stop	P0504GRX	0.5	◆Tire house trim, R&R
ABS REAR SENSOR, R&R	4SD,Both sides,With i-stop	P0504HRX	0.6	◆Tire house trim, R&R
LASER SENSOR, R&R	Without i-stop	P0509ARX	0.2	
LASER SENSOR, R&R	With i-stop	P0509BRX	0.3	
SMART CITY BRAKE SUPPORT SENSOR, R&R	One,Without i-stop	P0510ARX	0.5	◆Rear bumper assembly, R&R
SMART CITY BRAKE SUPPORT SENSOR, R&R	One,With i-stop	P0510BRX	0.6	◆Rear bumper assembly, R&R
SMART CITY BRAKE SUPPORT SENSOR, R&R	Two,Without i-stop	P0510CRX	0.5	◆Rear bumper assembly, R&R
SMART CITY BRAKE SUPPORT SENSOR, R&R	Two,With i-stop	P0510DRX	0.6	◆Rear bumper assembly, R&R
SMART CITY BRAKE SUPPORT CONTROL UNIT, R&R	Without i-stop	P0511ARX	0.3	
SMART CITY BRAKE SUPPORT CONTROL UNIT, R&R	With i-stop	P0511BRX	0.4	
P06 PARKING BRAKE				
PARKING BRAKE LEVER OR PEDAL ASSEMBLY, R&R	Without i-stop	P0601ARX	0.6	◆Parking brake, Adjust
PARKING BRAKE LEVER OR PEDAL ASSEMBLY, R&R	With i-stop	P0601BRX	0.7	◆Parking brake, Adjust
PARKING BRAKE CABLE [FRONT], R&R		P0602XRX	0.5	◆Parking brake, Adjust
PARKING BRAKE CABLE [REAR], R&R	[SKYACTIV-G 1.3,Rear parking brake cable]/[SKYACTIV-G 1.5,Without Coolant Control Valve,Rear parking brake cable]/[SKYACTIV-G 1.5,With Coolant Control Valve,Rear parking brake cable]	P0603ARX	0.8	◆Parking brake, Adjust

cardiagn.com

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
PARKING BRAKE CABLE [REAR], R&R	SKYACTIV-D 1.5,Rear drum brake type,Rear parking brake cable	P0603BRX	0.9	◆Parking brake, Adjust
PARKING BRAKE CABLE [REAR], R&R	SKYACTIV-D 1.5,Rear disc brake type,Rear parking brake cable	P0603CRX	0.8	◆Parking brake, Adjust
PARKING BRAKE CABLE [REAR], R&R	End cable,One side	P0603DRX	0.5	◆Parking brake, Adjust
PARKING BRAKE CABLE [REAR], R&R	End cable,Both sides	P0603ERX	0.8	◆Parking brake, Adjust
PARKING BRAKE SWITCH, R&R	Without i-stop	P0605ARX	0.2	
PARKING BRAKE SWITCH, R&R	With i-stop	P0605BRX	0.3	

cardiagn.com