NCR M-STATUSY ZMOTORYZOWANY CZYTNIK KART

M-01 BLANK TRACK

M-02 TRACK NOT SUPPORTED

M-03 READ ERROR

M-04 WRITE ERROR

M-05 NO CARD IN READER AT START OF COMMAND

M-06 CARD REMOVED BY USER DURING CAPTURE

M-07 SHUTTER JAMMED OPEN

M-08 SHUTTER SWITCH FAILURE DETECTED

M-09 ERROR RECOVERY SUCCESSFULL

M-10 SHUTTER JAMMED CLOSED

M-11 CARD JAM

M-12 CARD CAPTURED AFTER UNSUCCESSFUL EJECT

M-13 POSSIBLE CUSTOMER TAMPERING

M-14 TOO MANY CONSECUTIVE READ ERRORS OR BLANK KART ON ANY TRACK

M-15 TOO MANY COSECUTIVE WRITE ERRORS

M-16 14 TOO MANY CONSECUTIVE CARD JAMS

M-17 TOO MANY CONSECUTIVE SHUTTER JAMMED CLOSED

M-18 CARD JAM DURING CAPTURE

M-19 TOO MANY INVALID CARDS

M-20 DEVICE STILL INOPERATIVE

M-21 NO CARD ENTERED DURING CLEANING CYCLE TEST

M-22 SPEED OUT OF SPECIFICATION (FAST)

M-23 SPEED WITHIN +3%

M-24 SPEED WITHIN +-1%

M-25 SPEED WITHIN -3%

M-26 SPEED OUT OF SPECIFICATION (SLOW)

M-27 INVALID CARD DETECTED (DIAGNOSTICS ONLY)

M-28 UNDEFINED

M-29 UNDEFINED

M-30 UNDEFINED

M-31 UNDEFINED M-32 UNDEFINED M-33 CIM SERVICES TEST FAILED M-34 UNDEFINED M-35 ERROR IN TRACK 3 DATA M-37 CROPF FEATURE NOT SUPPORTED M-38 LFCC BIN FULL SOON/FULL M-39 UNDEFINED M-40 LFCC BIN REMOVED/NOT CONFIGURED M-41 CROPF FEATURE FAILURE M-42 UNDEFINED M-43 UNDEFINED M-44 UNDEFINED M-45 UNDEFINED M-46 UNDEFINED M-47 UNDEFINED M-48 UNDEFINED M-49 UNDEFINED M-50 CARD NOT IN SCRW STAGE POSITION M-51 SMART CARD STOPPER PIN OR CONTACTS LOWERED, UNABLE TO CAPTURE M-52 INVALID SMART CARD COMMAND CODE ERROR M-53 INVALID SMART CARD COMMAND DATA ERROR M-54 SCIF NOT CONFIGURED / NOT RESPONDING M-55 SCIF RESPONSE TIMEOUT EXCEEDED M-56 CARD READER IS IN SCRW MODE (DIAGNOSTIC ONLY) M-57 INVALID SMART CARD RESPONSE LENGH M-58 UNDEFINED M-59 UNDEFINED M-60 UNDEFINED M-61 UNDEFINED M-62 UNDEFINED

n	Λ.	63		1 / 1	Γ		N I	ГГ	•
ı١	/1-	กร	ι.	ш	ıjr	. – 1	IM	ГΙ	١.

M-64 INVALID SCIF COMMAND CODE

M-65 INVALID SCIF COMMAND FORMAT

M-66 NO SMART CARD ENCRYPTOR RESPONSE ERROR

M-67 INVALID KEY ID

M-68 INVALID KEY TYPE

M-69 UNDEFINED

M-70 INVALID KEY - DOES NOT EXIST

M-71 INVALID PASSWORD - NOT DECIMAL

M-72 INVALID PASSWORD - NO MATCH

M-73 KEY INTEGRITY ERRROR

M-74 KEY PARITY ERROR

M-75 INVALID DATA FORMAT

M-76 STOPPER PIN FAILURE

M-77 CONTACT UNIT FAILURE

M-78 CARD MOVEMENT FAILURE

M-79 SMART CARD SWITCH OFF FAILURE

M-80 SMART CARD REMOVED ERROR

M-81 NO SMART CARD RESPONSE

M-82 SMART CARD TRANSMISSION ERROR

M-83 SMART CARD SWITCHED OFF

M-84 ILLEGAL CARD TYPE / PARAMETER

M-85 POWER UP TIME EXCEEDED

M-86 ANSI X9.8 PIN BLOCK ERROR

M-87 CIM SELF TEST FAILED

M-88 CIM SECURITY MODULE DEFECTIVE

M-89 CIM SECURITY MODULE COMMUNICATION FAILURE

M-90 CIM INTERFACE BOARD DEFECTIVE

M-91 CIM INTERFACE BOARD COMMUNICATIONS FAILURE

M-92 UNDEFINED

M-93 UNDEFINED

M-94 UNDEFINED
M-95 UNDEFINED
M-96 UNDEFINED
M-97 UNDEFINED
M-98 UNDEFINED
M-99 UNDEFINED

DRUKARKA POTWIERDZEŃ

KLAWIATURA EPP

DYSPENSER