Continuation power flow in short

Camille Hamon

October 16, 2015

What you need

- 1. An initial operating point $x^0 = [\theta^0 V^0]$, for example obtained after a power flow computations.
- 2. A direction of load increase d (see slides).

How to proceed

- 1. Start at $x_i = x^0$, set k = 2n + 1 and $\lambda_i = 0$. Choose a step length s.
- 2. While $\lambda_i > 0$, do:
 - (a) Given k, x_i and λ_i , compute the tangent with the formula on the slide.
 - (b) Choose parameter k with the formula on the slide.
 - (c) Take a step from x_i and λ_i in the tangent direction to get a predicted point.
 - (d) Given k and the predicted point, correct the prediction to get x_{i+1} and λ_{i+1} (Newton-Raphson method).
 - (e) Set i = i + 1 and continue.

Notes

- 1. Usually, the algorithm starts with k corresponding to λ and switches to k corresponding to one of the voltage magnitudes before reaching the nose point. Once the nose point is passed, it then switches back to λ . So λ increases until the nose point and decreases again as we trace the lower part of the PV curves.
- 2. You can access Ajjarapu's book from the NTNU network: http://link.springer.com/book/10.1007/978-0-387-32935-2. In Chapter 3, "Continuation power flow", examples in simple systems are given. Note, however, that the way the load increase is defined in these examples is slightly different from the way it was defined in the lecture.