WM-G-MR-09
Application Circuit
WLAN 802.11b/g 8.2mmx8.4mm SiP Module

Block Diagram



Table of Contents

---

1 Blockdiagram
2 Schematic
3 Bluetooth Coexistence
4 Change History

1

USI 環隆電氣股份有限公司 Universal Scientific Industrial Co., Ltd.
Design Engineer : Camus Chen

Title	WM-G-MR-09 Application Circuit	
Size	Document Number <Doc>	Rev 0.2
Date: Friday, October 12, 2007	Sheet 1 of 4	

External sleep clock



External Reference Circuit for Clock source

Power

VDD_3.3 : Max Current rating = 300 mA

Host interface



Note : The signal level should be
the same as VDD_HOST_IO.
(Pin 9 of module)

Firmware Boot ROM select

	R4 (SCLK)	R5 (ECSn)
BOOT from SPI EEPROM	**No Load**	**100K**
BOOT from host interface bus	**No Load**	**No Load**

Host I/F Voltage

	R6	R8
Host I/F Voltage : 3.3V	**0R**	**NL**
Host I/F Voltage : 1.8V	**NL**	**0R**

WLAN Host Interface select

	R9 (IF_SEL_1)	R10 (IF_SEL_2)
SDIO	**No Load**	**No Load**
G-SPI	**100K**	**100K**

Keep GPIO[5] & GPIO[6] open for internal XTAL 38.4MHz

USI 環隆電氣股份有限公司 Universal Scientific Industrial Co., Ltd.
Design Engineer : Camus Chen
Title: WM-G-MR-09 Application Circuit
Size | Document Number <Doc> | Rev 0.2
Date: Friday, October 12, 2007 | Sheet 2 of 4

Level of WL_ACTIVE, BT_STATE and BT_PRIORITY are 1.8V







WL_ACTIVE	O	Bluetooth WLAN Active **2-Wire BCA Mode**: When high, WLAN is transmitting or receiving packets. **3-Wire BCA Mode**: 0 = Bluetooth device allowed to transmit 1 = Bluetooth device not allowed to transmit In 3/4WBCA mode, the signal output is programmable and can be low during both Bluetooth Rx and Tx timeslots. This pin drives low when PDn is asserted. In WLAN sleep mode, all I/O pads are powered down. This pad will stay at a low state when in power down mode.
BT_PRIORITY	I	Bluetooth Priority **2-Wire BCA Mode**: When high, Bluetooth is transmitting or receiving high priority packets. **3-Wire BCA Mode**: When high, Bluetooth is requesting to transmit or receive packets.
BT_STATE	I	Bluetooth State 0 = normal priority, Rx 1 = high priority, Tx BT_STATE is used to input the Bluetooth priority and direction of traffic following the assertion of the BT_PRIORITY input.

3

USI 環隆電氣股份有限公司
Universal Scientific Industrial Co., Ltd.

Design Engineer : Camus Chen

Title: WM-G-MR-09 Application Circuit

Size | Document Number <Doc> | Rev 0.2

Date: Friday, October 12, 2007 | Sheet 3 of 4

Change History

20070629: First Release

20070914:
U2 pin4 change to NC
U2 pin9 change to VDD3.3
Remove VDD_HOST_IO, R6, R8
Leave U2 pin4 & pin 36 as NC

20070917: Restore R6 & R8

20071012:
U2 pin9 restore to VDD_HOST_IO
Swap ST1G3234 pin A1, A3 and C1, C3
Sleep clock powered by VDD_HOST_IO
Add level description for WL_ACTIVE, BT_STATE and BT_PRIORITY

4

USI 環隆電氣股份有限公司 Universal Scientific Industrial Co., Ltd.

Design Engineer : Camus Chen

Title: WM-G-MR-09 Application Circuit

Size	Document Number	Rev
	<Doc>	0.1

Date: Friday, October 12, 2007 Sheet 4 of 4