



CAPRIOLE PRECAST ENGINE · V1.1

Building-Wise Tracking Manual

How to Update Cast Status for
In-House & By Others Panels



Audience: Site Engineers · Production Supervisors · QC Team

Module: Building Tracking Tab

Issued: May 2026

⚠ This document is for authorised team members
only.

Changes made here affect the live production
schedule.

1. Overview

The **Building-Wise Tracking** tab gives your team a real-time view of every precast panel across every building — who is casting it, which building it belongs to, and whether it has been completed.

Your project contains two types of panels:

Type	Description	Who casts?
In-House	Panels scheduled and cast in Capriole's own casting yard	Capriole production team
By Others	Panels originally assigned to an external sub-contractor	External contractor <i>or</i> Capriole (if reassigned)

i Important: In some situations, panels originally labelled *By Others* may end up being cast by Capriole's own yard instead. The tracking tab lets you record this without changing the original contract data.

1.1 Status States

Each building cell (B1, B2, B3 ...) for every panel type can be in one of three states:



Pending

Not yet cast · grey dash



Cast (By Others)

External contractor confirmed cast · green



Cast In-House

Capriole cast this instead · blue



In-House panels (green rows) are updated automatically by the engine when a day is marked complete in the Order Schedule. You **do not need to click** them manually.

1.2 Who Should Update This Tab?

- **Site Engineer / Production Supervisor** — marks By Others panels after confirming cast with the sub-contractor
- **QC Team** — verifies and counter-checks cast counts against delivery notes
- **Project Manager** — monitors overall % completion via the Print Report



Do not mark a panel as cast before physical confirmation. The system has no undo — an incorrect mark must be clicked again to cycle back to Pending.

2. Opening the Building Tracking Tab

- 1

Open the project in the Precast Engine.

Sign in to the cloud from the home screen and click your project card, or open a local `.pfproj` file.
- 2

Click the *Building Tracking* tab in the top navigation bar.

It is the second tab from the right, labelled  **BUILDING TRACKING**.
- 3

Select the correct floor using the floor tabs (e.g. `FF` , `GF`) shown below the title bar.

Each floor is tracked independently.

OVERVIEW | GANTT SCHEDULE | MOULD ASSIGNMENTS | ORDER SCHEDULE | TABLE PLAN | CASTING TABLES | **BUILDING TRACKING** | DATA

BUILDING-WISE TRACKING

FF floor · 36 of 208 panels cast (17%)

Print Report

Export CSV

FF

GF

Cast (By Others)

✓ IH

Cast In-House

Pending

By Others row — click to cycle: Pending → Cast IH → Cast

2.1 Reading the Table

Element ID	Family	Floor	Source	Total	Cast	Balance	B1	B2	B3	B4
FF-WL-01	WL	FF	In-House	4	2	2	✓	✓	—	—
FF-IP-01	IP	FF	By Others	4	2	2	✓	✓ IH	—	—
FF-IP-03	IP	FF	By Others	4	0	4	—	—	—	—

Column	Meaning
Element ID	Unique panel code (e.g. FF-IP-01)
Source	In-House (Capriole) or By Others (sub-contractor)
Total	Number of buildings requiring this panel type
Cast	How many buildings have confirmed this panel as cast
Balance	Remaining panels still pending (red = behind)
B1 ... Bn	Individual building status — click to update (By Others only)

Building-Wise Tracking Manual · Capriole Precast Engine v1.1

Page 3

3. Updating Cast Status

3.1 Marking a "By Others" Panel as Cast

When a sub-contractor confirms that a panel has been cast, follow these steps:

- 1 Navigate to **Building Tracking** and select the correct **floor tab** (FF or GF).
- 2 Find the panel row. **By Others** rows have an amber/cream background and show a red "By Others" source badge.
- 3 Locate the **building column** (B1, B2, B3 ...) for the specific building that has been cast.
- 4 **Click the cell once.** It will turn **✓ IH** (blue) — meaning *Cast In-House by Capriole*.
- 5 **Click again** to advance to **✓** (green) — meaning *Cast by the external contractor (By Others)*.
- 6 **Click a third time** to return to **—** (Pending) if you made an error.



Choose the correct state:

Use **✓ IH** (blue) when Capriole's own casting yard produced the panel.

Use **✓** (green) when the external sub-contractor produced the panel as per contract.

3.2 Cycle Summary



3.3 Marking In-House Panels as Cast

In-House panel cells in the Building Tracking table are **read-only** — you cannot click them directly here. Their status is driven by the **Order Schedule** tab. Follow these steps to mark an In-House panel as Cast:

- 1 Click the **ORDER SCHEDULE** tab in the top navigation bar.
- 2 Use the **Filter Bar** at the top of the table to narrow down the list:
 - Type the **panel code** (e.g. **GF-WL-01**) in the Search box, or
 - Click a **Family chip** (WL, IP, WN, PB) to filter by family, or
 - Click a **Building chip** to show only one building.
- 3 Find the correct panel row. The row shows: **Date • Table • Type • Building • Dimensions • Weight • Mould • Status**.
- 4 In the **Status** column, click the dropdown and change it from **Pending** to **✓ Cast** .
The row background turns **green** immediately to confirm.
- 5 Return to the **Building Tracking** tab — the corresponding building cell will now show a green **✓**.

6 Click  **Save Patch** in the top-right to sync changes to the cloud.

ORDER SCHEDULE — Daily Production Schedule

 Search type / code..

Family: **WL** **IP** **WN**

Status: **Pending** **Cast**

Date	Table	Type	Building	Dim. (mm)	Weight	Mould	Status
2026-05-05 · Monday							
	T01	GF-WL-01	Building 1	3200×500	1.24 t	 reuse	Pending ▼ 
	T01	GF-WL-02	Building 1	3200×500	1.24 t	 reuse	✓ Cast ▼ 

† GF-WL-02 changed to ✓ Cast — row turns green immediately. Click Pending to revert.

 If **Hide Completed Days** is turned on, fully-cast days collapse automatically. Use the filter bar to search for specific panel codes across all dates.

3.4 Auto-Save

Every click is **saved automatically** — there is no Save button needed. The status is stored in the project file. The next time you open the project, all statuses will be exactly as you left them.

 After marking panels, click  **Save Patch** in the top-right corner to sync your updates to the cloud. This ensures all team members see the latest status when they next open the project.

4. Generating Reports

4.1 Print Report (PDF)

Click the  **Print Report** button in the top-right of the Building Tracking tab. A new window will open with a formatted report that includes:

- Capriole logo and project details in the header
- Overall cast progress percentage
- SVG donut charts — one per floor showing % completion
- Horizontal bar chart showing progress per building
- Full panel tracking table with colour-coded cells

- 1 Click  **Print Report**. A print preview window will open automatically.
- 2 In your browser's print dialog, set **Paper size: A3** and **Orientation: Landscape**.
- 3 Enable "**Background graphics**" (or "Print backgrounds") so the coloured cells print correctly.
- 4 Select **Save as PDF** as the destination to generate a PDF file.
- 5 Share the PDF with stakeholders via email or WhatsApp.



The report only shows the **currently selected floor**. If you need reports for both FF and GF, print once per floor by switching the floor tab between prints.

4.2 Export CSV

Click  **Export CSV** to download a spreadsheet-compatible file containing:

Column	Content
S.NO	Row number
Element ID	Panel code
Family	Panel family (WL, IP, WN, PB)
Floor	Floor designation
Source	In-House or By Others
Total Qty	Number of buildings
Cast	Number of buildings cast
Balance	Remaining
B1 ... Bn	1 = cast, blank = pending (both green ✓ and blue ✓ IH are counted as 1)



Open the CSV in Microsoft Excel or Google Sheets to apply your own formatting, create pivot tables, or send progress summaries to the client.

4.3 Switching Between Floors

Use the floor tabs (**FF** / **GF**) immediately below the title. The selected floor tab will be highlighted. The Print Report and Export CSV will use the currently active floor.

5. Quick Reference Card

Cut out or print this page as a desk reference for your team.

 **Building Tracking — Status Guide**

Cell Colour	Label	Meaning	Who sets it?
	– (grey)	Pending — not yet cast	Default state
	✓ IH (blue)	Cast In-House by Capriole	Team clicks By Others cell (1st click)
	✓ (green)	Cast by external contractor	Team clicks By Others cell (2nd click) or auto from Order Schedule

Clicking Cycle (By Others cells only):

– Pending

 →

✓ IH Cast In-House

 →

✓ Cast by Others

 →

– Pending (reset)

 **Daily Workflow Checklist**

1. Open project from cloud or local file
2. Click **Building Tracking** tab
3. Select the correct floor (FF / GF)
4. For each confirmed cast — click the building cell once or twice
5. Verify **Cast** count matches your daily report
6. Click  **Save Patch** to sync to cloud
7. Print or export if a progress report is needed

 **Common Mistakes to Avoid**

- Marking a panel cast **before physical confirmation**
- Forgetting to **Save Patch** after updating (changes won't sync)
- Clicking In-House cells (they are **read-only**)
- Printing without switching to the correct **floor tab** first