



FLY INFORMED

Flight Briefing Assistant — User Guide

Updated 13 July 2026 · For reference only, not for operational use. The official hard-copy OFP governs flight operations. For individual use only.

1. Welcome to Sky Matrix

Sky Matrix turns your Operational Flight Plan (OFP) into a clean, categorised briefing and an in-flight companion: weights and fuel cross-checks, route, weather and NOTAMs, a live NAV LOG, crew rest planning, checklists, a dangerous-goods reference and cabin announcements — all on your own device, working offline once loaded. It is licensed per device and is powered by **Sky Matrix AI**, which reads OFPs from airlines worldwide and keeps improving.

For reference only. Sky Matrix must not be used for operational purposes. Always fly from the official hard-copy OFP and approved documents. Figures may occasionally be mis-read — verify everything against your OFP.

2. Getting access

2.1 The lock screen and your Device ID

Each licence is locked to one device. On the lock screen you'll see your **Device ID** (looks like SKM-XXXXXX). Enter your **email** (required), then choose **Start free trial** or **Subscribe**.

2.2 Your code is delivered into the app

- **Free trial:** enter your email and tap **Start free trial** — the code is issued and **activated automatically** on this device. No copy-pasting. (A copy is also emailed to you.)
- **Subscription:** tap **Subscribe**, complete checkout, then tap “**Already subscribed? Get my code**” on the lock screen. Enter the email you subscribed with and the code is pulled

in and activated. It's also emailed to you.

The 10-day trial needs **no credit card**. One trial per device. Once activated, the app stays unlocked on that device until the code expires — updates never re-ask for the code.

2.3 PIN & biometric

After activation you set a **PIN** (4–8 digits), and optionally Face ID / fingerprint. Every launch after that shows a quick Login (PIN or biometric) — not the code screen.

2.4 When your access expires

You'll get a 7-day countdown before expiry. After expiry, subscribe or start a new period to get a fresh code.

3. Installing Sky Matrix

3.1 iPhone / iPad (Web App — 20 seconds)

1. Open the Sky Matrix link in **Safari** (not Chrome — “Add to Home Screen” is a Safari feature).
2. Tap the **Share** icon.
3. Tap **Add to Home Screen**, then **Add**.
4. Sky Matrix now launches full-screen like a native app and works offline once loaded.

Because your MDM may block deleting old bookmarks: you never need a new bookmark after an update. The single Home-Screen icon always loads the latest version automatically.

3.2 Android — installing the APK (sideloading)

The Android app is distributed as a signed **APK** (it is not on the Play Store). Sideloaded is safe when you verify the file. Steps:

1. On your Android device, open the Sky Matrix **Download** page and tap **Android App** to download `skymatrix.apk`.
2. When prompted, allow “**Install unknown apps**” for your browser (Settings → Apps → your browser → Install unknown apps). This is expected for any direct APK.
3. **Verify the file before installing** (recommended): check its SHA-256 checksum against the value published on the **Privacy & Security** page. On a computer:

- Windows: `certutil -hashfile skymatrix.apk SHA256`

- macOS / Linux: `shasum -a 256 skymatrix.apk`

The output must match the published checksum exactly. If it doesn't, delete the file and re-download.

4. Tap the APK to install, then open Sky Matrix and activate as in Section 2.

The checksum is how you confirm the APK hasn't been tampered with. Only ever install the APK from the official Sky Matrix download link.

Updating Android: app content updates itself each launch; the APK shell (share-to-app, device-ID bridge) only changes when you install a new APK — re-download when a new build is announced in the changelog.

4. Finding your way around

4.1 The tab bar

Five areas: **Load**, **OPF Briefing**, **Inflight Display**, **Utilities** (checklists, dangerous goods and PA), and **Inflight Rest**. On tablet/landscape the two main modes sit on a left rail; on a phone they stack.

4.2 Identity bar & live clock

A UTC clock (internet-synced) runs on every page, with your callsign, route and date. If the clock can't verify against the internet it flashes red.

4.3 Theme (light / dark)

Sky Matrix follows your device's light/dark setting automatically. Use the ☼ **Light** / ☾ **Dark** button in the header to switch manually — your choice is remembered on that device.

4.4 Gestures

Swipe left/right to move between tabs. The screen stays awake while Sky Matrix is in front.

5. Load tab

The Load tab is organised as: **1 — Load an OFP**, then **2 — Flight tools**, then Send feedback.

5.1 Loading your OFP

1. Drop your OFP file on the loader, or tap to choose it (PDF or text).
2. Choose one: **Sky Matrix Briefing** (fast, offline, best on Qatar-style OFPs) or **Sky Matrix AI** (reads the OFP pages — most accurate across all airlines, needs internet).
3. The app fills the whole briefing and jumps you to the **OFP Briefing** tab. Your last OFP is remembered until you load another.

On Android you can open your OFP email, tap **Share** → **Sky Matrix** to load it straight in. On iPhone/iPad, open the PDF and use the file picker.

5.2 Crew roster (Sky Matrix AI)

Upload a roster — photo, PDF, Word or text. Sky Matrix AI reads flight-deck and cabin names by rank. Flight-deck ranks recognised: **CP / CAP / CAPT** (Captain) and **FO / SFO** (First Officer).

5.3 Checklist maker

Turn any document (PDF, Word, photo or text) into a tickable checklist. Choose **Sky Matrix AI** (clean steps) or **Line by line** (offline). It opens as a floating checklist you can keep open alongside your briefing (see 11.2).

Your PA scripts, translation and Announcement Prep now live under **Utilities** → **PA** (Section 8.3), keeping the Load tab focused.

6. OFP Briefing tab

Sub-tabs: **OFP**, **Route**, **Weather Alerts**, **NOTAMs & Enroute**.

6.1 OFP

Route, aircraft, weights with **ETOW vs MTOW** and **ELW vs MLW** cross-checks (red caution if a limit would be exceeded), fuel breakdown, remarks, alternate and time zones. A **Data check** banner flags missing or out-of-range fields before you rely on them.

6.2 Turbulence / wind shear

Cruise-level shear of **SR 4 or higher** is listed by **time after take-off**. If there is more than one turbulence band, they're shown in a table (from waypoint, max SR, time after take-off with projected UTC once you set take-off time, and duration).

6.3 Route, Weather, NOTAMs

Full route with FIRs and ETOPS/EDTO points; departure/enroute/arrival weather; and NOTAMs colour-coded by time window (red = active now, amber = window, green = clear).

7. Inflight Display tab

A clock bar with the internet-UTC time and a **DOCS** button. Sub-pages: **Departure** · **Live** · **Nav** · **Arrival**. The app remembers which sub-page you were on.

7.1 Departure

Auto-filled from the OFP. Tap **BLOCKS OFF** at push to stamp off-blocks. The **engine warm-up** timer begins **5 minutes after off-blocks** and runs for the minutes you set. A **Show departure NOTAMs** button opens the colour-coded list.

7.2 Live

- Tap **START** at lift-off (or **Arm GPS** for automatic capture) to record take-off time.
- Elapsed, time-to-go, ETA (UTC and destination local), and rest countdowns.
- **Post-takeoff check interval** is configurable — banners fire at **Top of Climb** and then every set number of minutes after take-off (default 30).
- Sunrise/sunset for departure, destination and en-route crossings.

7.3 Nav — NAV LOG

The **NAV LOG** compares your live GPS position against the OFP plan. It shows, in the layout below:

Dist flown	Dist to go	Time elapsed	Δ time at dest
Next WP	Dist to WP	Time to go (to WP)	
Plan ETA WP	Est ETA WP	Δ time (WP)	
Flt-plan fuel	Fuel EICAS/FMS	Δ fuel now	Δ fuel at dest

- **Next waypoint** is chosen automatically from your GPS position; you can override it from the dropdown.
- Enter your current fuel in **Fuel EICAS/FMS** to see the fuel comparison: how you stand against plan now, and the projected difference at destination.
- Distances and times come from the OFP nav log (every waypoint, including lat/long-only fixes); estimated ETAs use your current ground speed.

Below the NAV LOG: airport **weather & NOTAMs** with three colour-coded buttons in order —

D-ATIS (blue), **METAR/TAF** (green), **NOTAMs** (amber). For the selected airport these auto-refresh every 30 minutes.

7.4 Arrival

ETA (UTC and local), before-STA, parking and fuel fields. **D-ATIS auto-fills** the ATIS letter and the temperature (°C/°F). Your **landing time** captured on Live appears here. A **Show arrival NOTAMs** button and the engine **cool-down** timer (from landing) are here too, plus the **Descent PA** button.

8. Utilities tab

Sub-tabs: **Checklist** · **Dangerous Goods** · **PA**.

8.1 Checklist

Your own checklist — add items and tick them off. Use **Reset ticks** before each flight. (Build one-off checklists from any document with the **Checklist maker** on the Load tab, Section 5.3.)

8.2 Dangerous Goods (DGR)

Choose a hazard class and/or drill letter for the ICAO emergency-response guidance.

8.3 PA (announcements)

All your announcement needs in one place:

- **My announcements** — your own PA scripts/notes, saved on this device; Copy and Import .txt.
- **Translate** — paste any announcement, pick a language, translate (needs internet).
- **Announcement Prep** — upload a template (photo/PDF/text); Sky Matrix AI fills the blanks with this flight's data and your name, in your chosen language.

Welcome and **Descent** PAs are built on the **Departure** and **Arrival** pages (Inflight Display), where the flight details auto-fill. Everything else lives here under PA.

9. Inflight Rest

The rest window builds automatically (start = take-off + 15 min; end = take-off + trip – 60 min). Choose a rest pattern and see each crew member's slot and duration.

10. Cabin announcements (Welcome & Descent)

On **Departure** tap **Welcome PA**; on **Arrival** tap **Descent PA**. Crew, aircraft, destination, cruise level, ETA and local time auto-fill from the OFP and the live computation. Choose Captain or First Officer wording, then Copy to read out.

11. Handy extras

11.1 DOCS (your documents, on-device)

Tap **DOCS** in the clock bar to store PDFs and files on your device (private to you). Open a document and it appears in a **floating viewer** — no browser pop-up. Your administrator can also **push a document** (e.g. a bulletin) to your app; it arrives in DOCS the next time you open the app online.

11.2 Floating docs & checklists

Opened documents and made checklists stay open as **floating buttons** at the bottom-right — you can keep more than one open and switch between them while you read the briefing.

11.3 Aircraft / flight lookup, GPS, airports

- **Device GPS:** Sky Matrix uses your device's own GPS (an iPad/iPhone's built-in GPS, or a paired Bluetooth receiver such as a Garmin GLO feeding iOS Location Services). No pairing is required — arming GPS uses whatever the device provides.
- **Airports:** departure/destination resolve from a built-in list, from the OFP's own coordinates, or via a live global lookup that's cached for offline reuse — so time zones and sun times work almost anywhere.

12. Limitations & cautions

- **Reference only** — never operational. The official OFP governs the flight.
- Sky Matrix AI is still learning some airlines' formats; it may occasionally miss or mis-read a field. Cross-check against your OFP.
- PDF reading, live weather/ATIS, translation and the internet clock need internet; the core briefing works offline once loaded.
- The access gate is a per-device licence; keep your device secured with a strong PIN.

13. Troubleshooting

Symptom	What to do
Trial/subscribe code didn't activate	Check your email is correct; for a subscription use "Already subscribed? Get my code". A copy is always emailed.

"Access suspended"	Contact support@skymatrix.biz .
NAV LOG blank	Arm GPS and allow location permission; enter your EICAS fuel for the fuel comparison.
ETA local looks wrong	Ensure an OFP is loaded (destination coordinates drive the time zone).
Android won't install the APK	Allow "Install unknown apps" for your browser; verify the checksum (Section 3.2).
App looks out of date after an update	Reopen it online once; the Home-Screen icon always loads the latest version.

14. A typical flight, start to finish

1. Enter your email, get your code (trial auto-activates; subscription via "Get my code"), set a PIN, open Sky Matrix.
2. On **Load**, drop in your OFP and choose Briefing or Sky Matrix AI.
3. Review **OFP Briefing**: weights, fuel, route, weather, NOTAMs and any turbulence bands.
4. At the gate, open **Inflight Display** → **Departure**, tap **BLOCKS OFF**; the warm-up timer starts 5 min later.
5. At lift-off, go to **Live** and tap **START** (or **Arm GPS**). Watch elapsed, ETA and the TOC / post-takeoff banners.
6. In the cruise, use the **Nav** → **NAV LOG**: enter EICAS fuel to compare fuel/time/distance versus plan; plan crew rest.
7. On descent, open **Arrival** (ATIS/temp auto-filled), give the **Descent PA**, run the cool-down.
8. At the gate, tap **STOP — on-blocks** for block time and the end-of-flight summary.

FLY INFORMED

www.skymatrix.biz · support@skymatrix.biz

Prepared by Sky Matrix · For reference only, not for operational use.