DIGITAL COMMUNICATION



NAME:JIFAR WAKUMA AYANA ID NO:M202261027 INSTRUCTOR:ASSOCIATE PROFESSOR DU BING

SUMMARY

DG is the transfer of data or information using digital signals over a point-to-point (P2P) channel. A P2P connection is a mode of communication between two communication endpoints

Main purpose of communication:

to transfer information from a source to a recipient via a channel or medium.

Basic block diagram of a communication system:

Source Receiver Receiver Receiver

Why is digital important?

It reduces costs as a result of time savings in processes. It decentralises production by facilitating mobility and remote communication. It improves operational efficiency and productivity. It opens the door to new business opportunities and revenue streams, enabling the creation of new products and services.

Why Digital Communications?

- Better voice quality. ...
- Noise preservation and noise reduction. ...
- Deliver more information. ...
- Greater portability and flexibility. ...
- Simple to use.


Performance metric for analog systems is fidelity, for digital it is the bit rate and error probability

Goals in Communication System Design

maximize transmission rate, R
maximize system utilization, U
minimize bit error rate, Pe
minimize required systems bandwidth, W
minimize system complexity, Cx
minimize required power,

To


Math for digital communication



Linear filter channel with additive noise


To meet the specified bandwidth limitation

Wireline telephone channel



$$r(t) = s(t) * c(t) + n(t)$$
$$= \int_{-\infty}^{\infty} c(\tau)s(t-\tau) d\tau + n(t)$$

Linear time-variant (LTV) filter channel with additive noise



- Underwater acoustic
- Ionospheric radio (Freq. <30M)

 Mobile celluar radio

$$r(t) = s(t) \star c(\tau; t) + n(t)$$
$$= \int_{-\infty}^{\infty} c(\tau; t) s(t - \tau) d\tau + n(t)$$

- T is the argument for filtering. "age " variable
- t is the argument for time-dependence.
- The time-invariant filter can be viewed as a special case of the time-variant filter.

 $c(\tau;t)$ usually has the form

$$c(\tau;t) = \sum_{k=1}^{L} a_k(t) \delta(\tau - \tau_k)$$

where

- $\{a_k(t)\}_{k=1}^L$ represent the possibly time-varying attenuation factor for the L multipath propagation paths
- $\{\tau_k\}_{k=1}^L$ are the corresponding time delays.

Hence

$$r(t) = \sum_{k=1}^{L} a_k(t) s(t - \tau_k) + n(t)$$

- ✓ A Historical perspective in the development of digital communication The following below theorems/novel are very basic for digital communication
- Morse code (1837)
 - Variable-length binary code for telegraph
 - More frequent word uses shorter length, less frequent word uses longer length.
 - Dashes and dots
- Baudot code (1875)
 - Fixed-length binary code of length 5
 - Mark and space
- Nyquist (1924)
 - Determine the maximum signaling rate without intersymbol interference over, e.g., a telegraph channel

From this charles we have be shutter treomain Concepts: (D) Band pass tignal: - it is real 12gnal (XG) - o Jorall /22/2/2/2 * Hermitean symmetric - x other spectrum of a band pass X(-1) = X*(+) (-fourier transform (D) Bade band (LOW fass) fignal: - complex fignal XL(1)= o Forell |+|>hut & Bandwith XL(1)= o Forell |+|>hut & Bandwith XL(1)= o Forell |+|>hut & Bandwith XL(1)= o Forell |+|>hut & Bandwith

find our 90 an is to relate X(t) to X(t) Ruice Wester

- ku hu

Frantial State of St

X Sandpass Signal (7-70) + Xp*(-7-70] * Analytic Signa or 2 X4 (t) = Time-Lomain

pre-enleighe 2X4 (7)- frequency Lomain Low pass equelalent signager / Xq(t)=x(t)+12(t))é^{(27)70t}

Complex envelope

(X4(7)=2X(7+7)U-1(7+7) * evelope = | Xe(t) = \(\times_i^2(t) + \times_4^2(t) = \(\times_{(t)} \) * place Of (t) = tan (Exp (+) X: (t) * XUI+) X(t) = madulation * He maduation requires to generate & (+1) Hilber Harri John A X (t). X X Lt) - X (t) - demodulation