	1 '	2 3	
List of Parts in AFM Configuration			
Number	r Quantity	Component	Fusion 360 Sub-System
1_	1	Nanomax (Stage 1)	Nanomax
2	1	Adapter Plate (Stage 2)	Nanomax
3	1	Patch Cable (Laser 2)	Laser
4	1	Fiber Collimater (Laser 6)	Laser
5	1 1	Threaded Laser Adapter (Laser 5)	Laser
6	1	Kinematic Mount (Laser 3)	Laser
<sup>B</sup> 7	2	Small Tube Lens (Laser 4)	Laser
8	1	Plano-Convex Lens (Optics 7)	Laser
9	1	Zoom Lens Mount (Laser 7)	Laser
10	1	Nanomax Optics Adapter (3-D 4)	Nanomax
11	1	M2 x 6mm Cap Screw (Fast 7)	Fasteners
12	1	Digital Microscope Frame (3-D 6)	Nanomax
c 13	1	Quadrant Detector Sensor (Detect 10)	Reciever
14	2	Ground Glass Diffuser (Optics 9)	Reciever
15	1	Small Tube Lens-SM5 (Detect 9)	Reciever
16	1	Mini Tube Lens-SM5 (Detect 8)	Reciever
17	1	Small Coupler (Detect 7)	Reciever
18	1	Medium Tube Lens-SM5 (Detect 6)	Reciever
19	1	Thread Adapter (Detect 2)	Reciever
20	1	6-Axis Mount (Detect 1)	Reciever
21	1	Mini Tube Lens-SM1 (Detect 3)	Reciever
22	1	Plano-Convex Lens (Optics 8)	Reciever
23	1	Tube Adapter (Detect 5)	Reciever
24	4	M6 x 8 Cap Screw (Fast 8)	Fasteners
25	1	Magnetic Cantilever Holder (Stage 5)	Cantilever
E 26	1	Cantilever Holder (3-D 5)	Cantilever
27	1	Prism (Stage 6)	Cantilever
28	1	Cantilever Chip (Stage 7)	Cantilever
	Oust Caps (Al	AUX 1) can be used to cover these componence particulates from accumulating on the lens	