

**For Official Use Only**

		Master Frame														
		Minor Frame Count														
		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
Slot Count	1	6	6	6	6	6	6	6	6	6	6	6	6	6	6	6
	2	7	7	7	7	7	7	7	7	7	7	7	7	7	7	7
	3	9	11	13	4	4	9	11	5/8 <sup>1</sup>	5/8 <sup>1</sup>	S	9	11	2	2	S
	4	10	12	13	4	14	10	12	5/8 <sup>1</sup>	5/8 <sup>1</sup>	14	10	12	2	2	14

Note 1: Indicates that two (2) Types are transmitted in alternating Master Frames

Legend

2 = Special Message	10 = NGA Update
4 = Key	11 = IONO/IC/EOP Predictions
5 = Constellation Status	12 = ISC Message
6 = MICE I	13 = SA/A-S
7 = MICE II	14 = Authentication
8 = Reduced Almanac	"S"= Spare Slot
9 = MNAV Correction Table	

Figure 6-4. Nominal Navigation Frame