





SCENARIO-DRIVEN TIME-EVENT GENERATION

- TIME-MARK, SYNCHRONIZE GUI & EVENT-MODELS
- MANEUVER PRIMITIVES SEGMENTS
- PROGRAMMED POWER ADJUSTMENT
- SVID BASED MULTIPATH
- SVID BASED RAIM ANOMALIES


Script Sequence	
0.0	Speed 100.0 M/S
10.1	Turn 135.0° @1.0
33.8	Pitch 145.0° @1.0
59.3	Pitch 0.0° @1.0
65.6	R: P: Y: 180: 0: 0 o
68.8	Cruise 12.0 SEC
80.8	Pitch 360.0° @1.0
143.8	Cruise 10.0 sec
153.8	Turn 90.0° @1.0
169.7	Turn -90.0° @1.0
185.6	Cruise 10.0 sec



Click START / STOP for EVENT INTERVAL. Then select Event to apply From PULLDOWN





Interval will be marked in YELLOW





Click here to Toggle YELLOW INTERVAL Display

Script Sequence	
0.0	Speed 100.0 M/S
10.1	Turn 135.0° @1.0
33.8	Pitch 145.0° @1.0
59.3	Pitch 0.0° @1.0
65.6	R: P: Y: 180: 0: 0 o
68.8	Cruise 12.0 sec
80.8	Pitch 360.0° @1.0
143.8	Cruise 10.0 sec
153.8	Turn 90.0° @1.0
169.7	Turn -90.0° @1.0
185.6	Cruise 10.0 sec


Click to toggle display of MANEUVER SEGMENT



SCENARIO-DRIVEN MULTIPATH EVENTS



SCENARIO-DRIVEN POWER EVENTS



Click to toggle display of POWER EVENTS

MARKERS

- TMARK
- SEGMENT
- INTRVL

EVENTS

POWER

■ CLEAR

MULTIPATH

■ CLEAR

PROGRAMMABLE POWER EVENT

TIME OF APPLICABILITY 223971.0 ΔT 196.0 Seconds

RF OUTPUT 1 Apply to All Antennas

SVID Output Assignment

SATELLITE 6 GENERATED Add Remove

Elevation Profile

ELEVATION 21.0° AZIMUTH 223.0°

PROGRAMMABLE POWER LEVEL EVENT

Programmable Power / Attenuation Event

Apply to All Satellites Lock All Max 0

L₁ 0.0 dB L₂ 0.0 dB L₅ 0.0 dB


EVENT DURATION

Apply for Duration 60 seconds
 Clear for Duration
 Apply from Current Time to Simulation END
 Apply to ENTIRE Simulation

VEHICLE 1

CANCEL APPLY

If TIME-MARK is within an EVENT INTERVAL, this ICON marks the affected SVID



SCENARIO-DRIVEN RAIM EVENTS

