


LABBOX

NAVLABS

CLOSE LABBOX - USE SHORTCUT TO RESTART




MENU



SELECT THE SCENARIO FROM
USB DRIVE OR OTHER MEDIA

LABBOX WILL COPY SCENARIO
TO THE LABBOX HARD DRIVE



AFTER TRANSFER, PRESS
THE BUILD BUTTON TO
COMPLETE THE TRANSFER
PROCESS

PRESS TO BUILD
LABBOX FILES



MENU



TRANSFER



REMOTE CONTROL



CALIBRATE POWER



SW VERSION 1018

CONTROL
LABBOX VIA
ETHERNET

PLEASE SEE "CALIBRATION.PDF" FOR
INSTRUCTIONS ON CALIBRATING THE LABBOX.

CALIBRATION IS RECOMMENDED ONCE PER YEAR