NAVLABS

LABBOX
L_1 L_2 DESKTOP CONSTELLATION SIMULATOR



LABBOX is a 12 channel L_1 L_2 C/A, P GPS Constellation Simulator designed for Laboratory desk-top use. LABBOX will replicate any (Legacy) Tapestry Scenario faithfully in either *Scenario-Time* or *Real-Clock Time*.


SCENARIO LOADED INTO THE SIMULATOR READY TO RUN
LABBOX
NAVIGATION LABORATORIES INC.
LABBOX
COMPLEX3D
LOAD
RUN
MENU
STOP
ABCDEF
ABCDEFG
ANEWTESTOFTAPSHELL
ATESTNAME
AUGUSTROUTE
CALIBRATION
CLOSEDLOOP
COMPLEX3D
DEFAULT
DIGS
SELECT SCENARIO FOR OUTPUT
START RF OUTPUT
STOP RF OUTPUT
CLOSE LABBOX
BUILT IN TEST
OUTPUT TIME OPTIONS
TRANSFER SCENARIO FROM MEDIA TO LABBOX
BUILT IN TEST
POWER CALIBRATION

LOAD

THE LOADED SCENARIO IS SHOWN HERE

COMPLEX3D

SELECT SCENARIO TO OUTPUT

TO ADD SCENARIOS USE THE TRANSFER FUNCTION [MENU]

RUN

PAUSE /RESUME
STATUS DISPLAY

NEXT SCREEN
(OF 3)

STARTS THE [LOADED] SCENARIO OUTPUT





CLICK THIS TO RETURN TO RUN STATUS SCREEN 1

SHOW THE RUN STATUS AND POWER SCREEN





USE GREEN EXIT TO SAVE CHANGES, RED = QUIT

USES SCENARIO TIME UNLESS YOU ENTER OTHERWISE





CHECK TO OUTPUT SCENARIO WITH PC-CLOCK-TIME, OTHERWISE ENTER DESIRED START TIME (IF OTHER THAN SCENARIO TIME)



SELECT THE SCENARIO FROM USB DRIVE OR OTHER MEDIA



CALIBRATE

SEE THIS DOCUMENT FOR CALIBRATION PROCEDURES







? +5V / +12V FAIL
CHECK THAT BOTH AC PLUGS ARE ATTACHED,

CHECK FUSE (1.5 A)

LABBOX SETUP

800 X 600 TOUCH SCREEN.

ATTACH MONITOR TO MOUNT ON THE TOP OF THE CHASSIS.

2 PLUGS

DOUBLE CLICK LABBOX SHORT CUT