	1			3)		4		5			¬°
A												1
Ц												F
В												
												ľ
H												H
							slick on mouse n	aintar arraw on t	an of right toolbar			
							and double-click	on sheet to oper	op of right toolbar 1			
							Sheet: power	Sheet: usb	Sheet: blinkey	Sheet: ram	Sheet: sdcard	
c												10
		[П
		HOLE	∄⊟ HOFE									П
		gND ∓ T	₩				File: power.sch	File: usb.sch	File: blinkey.sch	File: ram.sch	File: sdcard.sch	1
		! 1					Sheet: gpio	Sheet: gpdi	Sheet: analog	Sheet: wifi	Sheet: flash	,
		GND	GND									П
		;										П
Ц		五 HOFE	S D D D D D D D D D D D D D D D D D D D									ıL
		Ξ Ψ	ъщ				File: gpio.sch	File: gpdi.sch	File: analog.sch	File: wifi.sch	File: flash.sch	1
			٦									\dashv
		GND	enu →									
		!										
							Root sheet					
							EMARD					
							Sheet: / File: ulx3s.sch					7.
4							File: ulx3s.sch					Jº
							Title: ULX3S					╛
							Size: A4	Date:			Rev: 1.8.11	1
							KiCad E.D.A. kic	ad 5.0.0-rc2+dfsg	1-2		ld: 1/11	_
	1			3)	l	4		5			_6



















