

## Unit 202: Electrical principles and processes for building services engineering

# Outcome 6 Undertake basic electrical tasks




#### **Electrical continuity bonding**






Equipotential bonding
Supplementary bonding
Cross bonding
Temporary continuity bonding










#### **Equipotential bonding**

- All metal parts within the building must be joined to the earth cable
- All services oil, gas, water and electricity along with any exposed metal
- Cable is then joined to the building's electrical system
- If a fault occurs, the electrical current would have a direct route through the wiring, stopping the person touching the metal object from getting a shock
- The earth cable used is 10mm<sup>2</sup>, and runs from each supply back to the main earth terminal at consumer unit
- Bonding provides equal potential between metal parts.



#### **Equipotential bonding**

All main metal work and utilities connected from earth bar in 10mm<sup>2</sup> cable.





#### **Supplementary bonding**

This maintains earth continuity throughout the **whole**, using 6mm<sup>2</sup> earth cable. Earth clips are made to BS951 and should be placed on clean pipework. The label says **Safety electrical connection do not remove**. To avoid unsightly wiring, continuity bonds are placed behind appliances or in airing cupboards.

As plumbers, if we disconnect a hot or cold service etc, it is our responsibility to make sure the earth clip is reinstated.










#### Supplementary bonding


Joining all individual pipes together in 6mm<sup>2</sup> cable, which in turn connects to the equipotential.





#### **Cross bonding**

Maintains earth continuity if plastic components are used (push-fit, water meters etc). 6mm<sup>2</sup> cable is used again.





#### **Temporary continuity bonding**

When plumbers cut into pipework, the earth continuity is broken, so the plumber could become the earth and therefore get an electric shock. Before cutting into pipework always use temporary continuity bonds.

1.5m long, made with 10mm<sup>2</sup> cable, with crocodile clamps

at either end.





#### To attach an earth continuity clamp you must:

- 1. Identify the correct pipe.
- 2. Clean the pipe (no paint).
- 3. Secure the clamp tightly on pipe.
- 4. Secure the earth cable tightly in clamp.
- 5. Check label is in place.
- 6. Test continuity.





#### Heating engineer electrocuted

A heating engineer has died following an electric shock while attempting to repair a central heating system. The 39-year-old engineer was carrying out work in a flat in St Paul's Mews in Birmingham when he suffered an electric shock and hit his head.

His two colleagues – one of whom is believed to be his nephew – and the householder made attempts to resuscitate him before paramedics arrived at the scene. The engineer was taken to the City Hospital where he later died.

SAVVAS, C. (2011) Engineer Electrocuted while working in Birmingham city centre flat. *Birmingham Mail*. 21<sup>st</sup> October. Available from: http://www.birminghammail.co.uk/news/local-news/engineer-electrocuted-while-working-in-birmingham-city-163803 [Accessed 25th January 2013].




#### **Earth continuity test**

This is where the installer tests to make sure all the metal work (pipes, boilers, appliances, metal sinks etc) is safely connected to the main earth bar at the consumer unit. This keeps everybody safe.

- 1. Find a known earth source (screw on cover or earth terminal).
- 2. Low reading OHM meter (or buzzer).
- 3. Place one probe on the known earth.
- 4. Place the second probe on appliance casing or pipework.
- 5. It should show a low reading (or buzz).











#### **Short circuit**

If the live accidently touches the earth, an earth fault will occur. This means the fuse may blow or the MCB will trip.

If the live accidently touches the earth, a short circuit will occur. This means the fuse will blow or the RCD will trip.



#### **Polarity test**

This must first be carried out **dead** before allowing any electricity.

- Is live connected to live?
- Is neutral connected to neutral?
- Is earth connected to earth?

On a circuit, you can connect the live and earth together, then go to the other end of the circuit and test. The low reading ohm meter needs to be set on ohms. By operating any switches you can also check the polarity (i.e. all switches must be in the live conductor only)



#### **Polarity test**

If the dead test proves successful, you can make the system live and re-test. This time the multimeter needs to be set on voltage (230v).

Probes: **Live** and **neutral** = 230v

**Live** and **earth** = 230v

**Neutral** and **earth** = 0v

If these readings are different, polarity is incorrect.



#### Socket tester

A simple way to test polarity in a domestic socket is by using a socket tester. Plug it in and switch the socket on: if all three lights come on, the socket is fine.













Differing wire strippers or side cutters (all insulated)






Assorted electrical screwdrivers (all insulated)




#### 3 pin plug

Maximum 13 amp rating and found on most domestic appliances. On new appliances, they come moulded but some appliances may need the plug replacing.













#### **Electrical clamps and terminals**

Pillar terminal




Claw type terminal





Screw or nut head terminal

Strip connector



Commonly found in terminals that plumbers use



