
fsm light p\_lamp / p\_lamp=0 e=1 next= now() + T p\_lamp / p\_lamp=0 e=1 next= now() + T OFF ON now()< next ^p\_lamp / e=1  $now() >= next / \neg e$ 

## fsm alarm

codigo\_ok / codigo\_ok=0 buzzer=1



buzzer=1 codigo\_ok= 0

presencia=0 buzzer=0

