

ECP5 and ECP5-5G Hardware Checklist

Technical Note



Contents

Acr	cronyms in This Document	3
1.	Introduction	4
2.	Power Supplies	5
2	2.1. ECP5 and ECP5-5G SERDES/PCS Power Supplies	5
2	2.2. Power Estimation	6
3.	Configuration Considerations	7
4.	I/O Pin Assignments	8
5.		
6.	·	
7.		
8.	HSUL and SSTL Pin Assignments	9
9.	<u> </u>	
10.		
Tec	echnical Support Assistance	
	evision History	
Та	ables	
Tab	ble 2.1. ECP5 and ECP5-5G FPGA Power Supplies	5
Tak	ble 3.1. JTAG Pin Recommendations	7
Tab	ble 3.2. Pull-up/Pull-down Recommendations for Configuration Pins	7
Tab	ıble 3.3. Configuration Pins Needed per Programming Mode	7
		10



Acronyms in This Document

A list of acronyms used in this document.

Acronym	Definition		
BGA Ball Grid Array			
CML Current-Mode Logic			
LUT Look Up Table			
LVCMOS Low-Voltage Complementary Metal Oxide Semiconductor			
LVDS Low-Voltage Differential Signaling			
PCB Printed Circuit Board			



1. Introduction

When designing complex hardware using the ECP5™ and ECP5-5G™ FPGA, designers must pay special attention to critical hardware configuration requirements. This technical note steps through these critical hardware implementation items relative to the ECP5 and ECP5-5G device. The document does not provide detailed step-by-step instructions but gives a high-level summary checklist to assist in the design process.

The device family consists of FPGA LUT densities ranging from 25K to 85K. This technical note assumes that the reader is familiar with the ECP5 and ECP5-5G device features as described in ECP5 and ECP5-5G Family Data Sheet (FPGA-DS-02012). The data sheet includes the functional specification for the device. Topics covered in the data sheet include but are not limited to the following:

- High-level functional overview
- Pinouts and packaging information
- Signal descriptions
- Device-specific information about peripherals and registers
- Electrical specifications

Refer to ECP5 and ECP5-5G Family Data Sheet (FPGA-DS-02012) for details. The critical hardware areas covered in this technical note are:

- Power supplies as they relate to the ECP5 and ECP5-5G power supply rails and how to connect them to the PCB and the associated system
- Configuration mode selection for proper power-up behavior
- Device I/O interface and critical signals

Important: Users should refer to the following documents for detailed recommendations.

- (TN1260) ECP5 and ECP5-5G sysCONFIG Usage Guide
- (TN1261) ECP5 and ECP5-5G SERDES/PCS Usage Guide
- (TN1262) ECP5 and ECP5-5G sysIO Usage Guide
- (TN1263) ECP5 and ECP5-5G sysClock PLL/DLL Design and Usage Guide
- (TN1264) ECP5 and ECP5-5G Memory Usage Guide
- (TN1265) ECP5 and ECP5-5G High-Speed I/O Interface
- (TN1266) Power Consumption and Management for ECP5 and ECP5-5G Devices
- (TN1267) ECP5 and ECP5-5G sysDSP Usage Guide
- (TN1114) Electrical Recommendations for Lattice SERDES
- (TN1033) High-Speed PCB Design Considerations
- (TN1068) Power Decoupling and Bypass Filtering for Programmable Devices
- (TN1084) LatticeSC[™] SERDES Jitter
- HSPICE SERDES simulation package (available under NDA, contact the license administrator at lic_admin@latticesemi.com)
- ECP5 and ECP5-5G-related pinout information can be found on the Lattice website.



2. Power Supplies

The V_{CC}, V_{CCAUX} and V_{CCIO8} power supplies are monitored to determine the ECP5 and ECP5-5G internal "power good" condition during power-up. These supplies need to be at a valid and stable level before the device can become operational and be configured. All other V_{CCIOX} are not monitored during power-up, but need to be at valid and stable level before the device is configured and entered into User Mode. Several other supplies including V_{CCA}, V_{CCAUXA}, V_{CCHTX} and V_{CCHTX} are used in conjunction with on-board SERDES on LFE5UM/LFE5UM5G devices. Table 2.1 lists the power supplies and the appropriate voltage levels for each supply.

Table 2.1. ECP5 and ECP5-5G FPGA Power Supplies

Supply	Voltage (Nominal Value)	Description
V _{CC}	1.1 V (LFE5U/5UM) 1.2 V (LFE5UM5G)	FPGA core power supply.
V _{CCA} 1.1 V (LFE5UM) 1.2 V (LFE5UM5G)		Analog power supply for SERDES blocks (For LFE5UM/LFE5UM5G devices). Should be isolated and "clean" from excessive noise.
V _{CCAUX}	2.5 V	Auxiliary power supply
V _{CCIO[0-4, 6-8]} ¹	1.2 V to 3.3 V	I/O power supply. Seven (eight on LFE5/LFE5UM5G-85 in 756 and 554 caBGA) general purpose I/O banks. Each bank has its own V _{CCIO} supply: V _{CCIO} is used in conjunction with pins dedicated and shared with device configuration, include JTAG. V _{CCIO} , 2, 3, 4, 6, and V _{CCIO} are optionally used based on per bank usage of I/O.
V _{CCHRX}	1.1 V (LFE5UM) 1.2 V (LFE5UM5G)	Input terminate voltage supply for SERDES inputs (For LFE5UM/LFE5UM5G devices)
V _{ССНТХ}	1.1 V (LFE5UM) 1.2 V (LFE5UM5G)	Output driver/termination voltage supply for SERDES outputs (for LFE5UM/LFE5UM5G devices)
V _{CCAUXA}	2.5 V	Auxiliary power supply for SERDES (for LFE5UM/LFE5UM5G devices)

Note:

1. Bank 4 exists only on the LFE5/LFE5UM5G-85 device in 756 caBGA and 554 caBGA. It is not available in any other device/package combinations. When migrating LFE5/LFE5UM5G-85 to lower density devices, I/Os on Bank 4 cannot be used.

The ECP5 and ECP5-5G FPGA device has a power-up reset state machine that monitors various power supplies.

These supplies should come up monotonically. The on-chip Power-On-Reset (POR) is de-asserted when the following conditions are met:

- Vcc reaches 0.9 V or above
- V_{CCAUX} reaches 2.0 V or above
- V_{CCIO8} reaches 0.95 V or above

Initialization of the device will not proceed until the last power supply above has reached its minimum operating voltage.

2.1. ECP5 and ECP5-5G SERDES/PCS Power Supplies

Supplies dedicated to the operation of the SERDES/PCS include V_{CCA} , V_{CCHRX} , and V_{CCHTX} . All V_{CCA} supply pins must always be powered to the recommended operating voltage range with the LFE5UM/LFE5UM5G devices. However, if no SERDES is used at all in these devices, all power supply pins for the SERDES can be connected to GND (V_{CCA} , V_{CCAUXA} , V_{CCHRX} and V_{CCHTX}).

When SERDES is used in the ECP5 and ECP5-5G devices, V_{CCHRX} and V_{CCHTX} can be left floating for unused SERDES channels. Unused channel outputs should be left tri-stated.

On migrating across the ECP5, ECP5UM, and ECP5UM5G devices on same package, refer to the LFE5U to LFE5UM/LFE5UM5G and LFE5UM to LFE5UM5G Migration section for more details.

It is very important that the V_{CCA} supply be low-noise and isolated from heavily loaded switching supplies. Refer to Electrical Recommendations for Lattice SERDES (TN1114) for recommendations.

© 2014-2017 Lattice Semiconductor Corp. All Lattice trademarks, registered trademarks, patents, and disclaimers are as listed at www.latticesemi.com/legal. All other brand or product names are trademarks or registered trademarks of their respective holders. The specifications and information herein are subject to change without notice.



2.2. Power Estimation

Once the ECP5 and ECP5-5G device density, package and logic implementation is decided, power estimation for the system environment should be determined based on the Power Calculator provided as part of the Lattice Diamond® design tool. When estimating power, the designer should keep two goals in mind:

- Power supply budgeting should be based on the maximum of the power-up in-rush current, configuration current and maximum DC and AC current for the given system's environmental conditions.
- The ability for the system environment and ECP5 and ECP5-5G device packaging to be able to support the specified
 maximum operating junction temperature. By determining these two criteria, the ECP5 and ECP5-5G device power
 requirements are taken into consideration early in the design phase.



3. Configuration Considerations

The ECP5 and ECP5-5G device includes provisions to configure the FPGA via the JTAG interface or several modes utilizing the sysCONFIG port. The JTAG port includes a 4-pin interface. The interface requires the following PCB considerations.

Table 3.1. JTAG Pin Recommendations

JTAG Pin	PCB Recommendation
TDI	4.7 kΩ pull-up to V _{CCIO8}
TMS	4.7 k Ω pull-up to V_{CCIO8}
TDO	4.7 kΩ pull-up to V _{CCIO8}
TCK	4.7 kΩ pull-down to GND

Every PCB is recommended to have easy access to FPGA JTAG pins, even if the primary configuration interface is not using the JTAG port. This JTAG port enables debugging in the final system. For best results, route the TCK, TMS, TDI and TDO signals to a common test header along with V_{CCIO8} and ground.

Using JTAG for configuration, the MODE pins are not used. Using other programming modes requires the use of the CFG[2:0] input pins. The CFG[2:0] pins include internal weak internal pull-ups. It is recommended that 1-10 k Ω external resistors be used when using these sysCONFIG modes. Pull-up resistors should be connected to V_{CCIO8}.

External resistors are always needed if the configuration signals are being used to handshake with other devices. Recommended pull-up resistors to V_{CCIO8} and pull-down to board ground should be used on the following pins.

Table 3.2. Pull-up/Pull-down Recommendations for Configuration Pins

	<u> </u>
Pin	PCB Connection
PROGRAMN	4.7 k Ω pull-up to V_{CCIO8}
INITN	4.7 k Ω pull-up to V_{CCIO8}
MCLK/CCLK	1 k Ω pull-up to V_{CCIO8}
CSSPIN	4.7 k Ω to 10 k Ω pull-up to V_{CCIO8}
CFG[2:0]	1 kΩ to 10 kΩ pull-up to V_{CCIO8} , 0 = GND. See Table 3.3.

Table 3.3. Configuration Pins Needed per Programming Mode

Configuration	Bus	Dedicated	Clock		Shound Bins	Dedicated Pins	
Mode	Size	CFG[2:0]	Pin	1/0	Shared Pins	Dedicated Pilis	
SSPI	1 Bit	001	CCLK	Input	MISO, MOSI, SI, DOUT,	PROGRAMN, INITN, DONE	
MSPI	1 Bit	010	MCLK	Output	MISO, MOSI, CSSPIN, DOUT	PROGRAMN, INITN, DONE	
	2 Bits				D[1:0], CSSPIN, DOUT		
	4 Bits				D[3:0], CSSPIN, DOUT		
SCM	1 Bit	101	CCLK	Input	DI, DOUT	PROGRAMN, INITN, DONE	
SPCM (Parallel)	8 Bits	111	CCLK	Input	D[7:0], DOUT, CSON, BUSY, WRITEN, CSN, CS1N	PROGRAMN, INITN, DONE	
JTAG	1 Bit	XXX	TCK	Input	_	TCK, TMS, TDI, TDO	



4. I/O Pin Assignments

The V_{CCA} provides a "quiet" supply for the SERDES blocks. For the best jitter performance, careful pin assignment will keep "noisy" I/O pins away from "sensitive" pins. The leading causes of PCB related SERDES crosstalk is related to FPGA outputs located in close proximity to the sensitive SERDES power supplies. These supplies require cautious board layout to insure noise immunity to the switching noise generated by FPGA outputs. Guidelines are provided to build quiet filtered supplies for the V_{CCA} , however, robust PCB layout is required to insure that noise does not infiltrate into these analog supplies.

Although coupling has been reduced in the device packages of ECP5 and ECP5-5G devices where little crosstalk is generated, the PCB board can cause significant noise injection from any I/O pin adjacent to SERDES data, reference clock, and power pins as well as other critical I/O pins such as clock signals. Electrical Recommendations for Lattice SERDES (TN1114) provides detailed guidelines for optimizing the hardware to reduce the likelihood of crosstalk to the analog supplies. PCB traces running in parallel for long distances need careful analysis. Simulate any suspicious traces using a PCB crosstalk simulation tool to determine if they will cause problems.

It is common practice for designers to select pinouts for their system very early in the design cycle. For the FPGA designer, this requires a detailed knowledge of the targeted FPGA device. Designers often use a spreadsheet program to initially capture the list of the design I/Os. Lattice Semiconductor provides detailed pinout information that can be downloaded from the Lattice Semiconductor website in .csv format for designers to use as a resource to create pinout information. For example, by navigating to the pinout.csv file, the user can gather the pinout details for all the different package offerings of the device in the family, including I/O banking, differential pairing, Dual Function of the pins, and input and output details.

5. Clock Inputs

The ECP5 and ECP5-5G device does not provide dedicated pins for clock inputs. All clock inputs are shared with the General Purpose I/O pin. When the pin is not used for clocking, the user can use it as a general purpose I/O pin. However, when these pins are used for clocking purpose, the user needs to pay attention to minimize signal noise on these pins. Refer to Technical Note ECP5 and ECP5-5G High-Speed I/O Interface (TN1265).

These shared clock input pins can be found under the Dual Function column of the pinlist csv file.

6. Pinout Considerations

The ECP5 and ECP5-5G supports many applications with high-speed interfaces. These include various rule-based pinouts that need to be understood prior to implementation of the PCB design on these high-speed interfaces. The pinout selection must be completed with an understanding of the interface building blocks implemented in the FPGA fabric. These include IOLOGIC blocks such as DDR, clock resource connectivity, and PLL and DLL usage. Refer to Technical Note ECP5 and ECP5-5G High-Speed I/O Interface (TN1265) for rules pertaining to these interface types.

7. LVDS Pin Assignments

True LVDS inputs and outputs are available on I/O pins on the left and right sides of the devices. Top and I/O banks do not support True LVDS standard, but can support emulated LVDS outputs. True LVDS input pairing on left and right banks can be found under the Differential column in the pinlist csv file. True LVDS output pair are available on any A and B pair of the left and right banks.

Emulated LVDS output are available on pairs around all banks, but this will require external termination resistors. This is described in ECP5 and ECP5-5G sysIO Usage Guide (TN1262).

© 2014-2017 Lattice Semiconductor Corp. All Lattice trademarks, registered trademarks, patents, and disclaimers are as listed at www.latticesemi.com/legal. All other brand or product names are trademarks or registered trademarks of their respective holders. The specifications and information herein are subject to change without notice.



8. HSUL and SSTL Pin Assignments

The HSUL and SSTL interfaces are referenced I/O standards require an external reference voltage. The V_{REF} pin(s) should get high priority when assigning pins on the PCB. These pins can be found in the Dual Function column with V_{REF1} label. Each bank includes a separate V_{REF} voltage. V_{REF1} sets the threshold for the referenced input buffers. Each I/O is individually configurable based on the bank's supply and reference voltages.

9. SERDES Pin Considerations

High-speed signaling requires careful PCB design. Maintaining good transmission line characteristics is a requirement. A continuous ground reference should be maintained with high-speed routing. This includes tightly matched differential routing with very few discontinuities. Refer to High-Speed PCB Design Considerations (TN1033) for suggested methods and guidance.



10. LFE5U to LFE5UM/LFE5UM5G and LFE5UM to LFE5UM5G Migration

Besides migrating design from one device to another device (i.e. LFE5U-25 to LFE5U-45) on same package (i.e. caBGA554) within its own family in LFE5U and LFE5UM/LFE5UM5G, user can migrate from the non-SERDES (LFE5U) device to SERDES (LFE5UM) device, or migrating from LFE5UM device to LFE5UM5G device in the same package.

If the user anticipates his design, he may use SERDES at a later time of his product. He would first design, and make all the connections to all SERDES circuit on board.

For example, if the user anticipates the need to use the two Dual SERDES on LFE5U-85 product, he has to design his board with LFE5UM, which contains the SERDES ports, to the not-yet-populated SERDES circuit on the board. This requires all SERDES power pins to be connected to power sources on the board, with the corresponding pins found on the LFE5U device. Note these power pins on the ECP5U devices are required to be connected to GND when migrating to LFE5UM is not considered, but they need to be connected to Serdes power supplies when future migration is considered. He can still put in the LFE5U-85 device because the two devices are pin compatible, other than the SERDES pins and Serdes power supply pins. Also to be taken into account is to ensure the Serdes power supplies are isolated and implemented with different power rails, to minimize any noise injection from other supplies.

When designing the board with LFE5UM and plan for future migration to LFE5UM5G to increase the SERDES throughput to 5G, care has to be taken that the Vcc/Vcca/Vcchrx/Vcchtx need to be powered by 1.2 V nominal supply voltage for LFE5UM5G. Voltage regulators with adjustable voltage between 1.1 V and 1.2 V are needed when selecting to populate the board with either the LFE5UM or LFE5UM5G device.

The other consideration to migrate between the LFE5UM and LFE5UM5G devices is to ensure the signal quality of the Rx and Tx traces, which needs to be good for 5Gbps operation.

Another consideration when migrating between the LFE5UM and LFE5UM5G devices is that if the reference clock supply from a source that cannot be changed, such as PCle slot clock (100 MHz), the clock input to the LFE5UM5G needs 2X frequency of this clock source. An external clock generator, such as PLL, needs to be used to double this clock frequency (to 200 MHz) when used with LFE5UM5G device.

Table 10.1. Hardware Checklist

	Item				
1	FPGA Power Supplies				
1.1	V _{CC} core @ 1.1 V ±5% (LFE5U/LFE5UM), @ 1.2 V +/- 5% (LFE5UM5G)				
1.1.1	Use a PCB plane for V _{CC} core with proper decoupling				
1.1.2	V _{CC} core sized to meet power requirement calculation from software				
1.2	V _{CCA} @ 1.1 V ±5% (LFE5UM), @1.2 V ±3% (LFE5UM5G)				
1.2.1	V _{CCA} "quiet" and isolated"				
1.2.2	V_{CCA} pins should be ganged together and a solid PCB plane is recommended. This plane should not have adjacent non-SERDES signals passing above or below. It should also be isolated from the V_{CC} core power plane.				
1.3	All V _{CCIO} are between 1.2 V to 3.3 V				
1.3.1	V _{CCIO8} used with configuration interfaces (i.e. memory devices). Need to match specifications.				
1.3.2	V _{CCIO} [1:7] used based on user design				
1.4	V _{CCAUX} and V _{CCAUXA} @ 2.5 V ±5%				
1.6	Power estimation				
2	SERDES Power Supplies				
2.3	V _{CCHRX} and V _{CCHTX} connected for USED SERDES channels				
2.3.1	V _{CCHTX} are at 1.1 V ±5% (LFE5UM), 1.2 V ±5% (LFE5UM5G)				
2.3.2	V _{CCHRX} are from 0.3 V to 1.1 V +5% (LFE5UM), 0.3 V to 1.2 V +5% (LFE5UM5G)				
3	Configuration				
3.1	Pull-ups and pull-downs on configuration specific pins				
3.2	V _{CCIO8} bank voltage matches sysCONFIG peripheral devices such as SPI Flash				

© 2014-2017 Lattice Semiconductor Corp. All Lattice trademarks, registered trademarks, patents, and disclaimers are as listed at www.latticesemi.com/legal. All other brand or product names are trademarks or registered trademarks of their respective holders. The specifications and information herein are subject to change without notice.



	Item	ОК	NA	
4	SERDES			
4.1	Dedicated reference clock input from clock source meets the DC and AC requirements			
4.1.1	External AC coupling caps may be required for compatibility to common-mode levels			
4.1.2	Ref clock termination resistors may be needed for compatible signaling levels			
4.2	Maintain good high-speed transmission line routing			
4.2.1	Continuous ground reference plane to serial channels			
4.2.2	Tightly length matched differential traces			
4.2.3	Do not pass other signals on the PCB above or below the high-speed SERDES without isolation.			
4.2.4	Keep non-SERDES signal traces from passing above or below the V_{CCA} power plane without isolation.			
5	Special Pin Assignments			
5.2	V _{REF} assignments followed for single-ended SSTL inputs			
5.2.1	Properly decouple the V _{REF} source			
6	Critical Pinout Selection			
6.1	Pinout has been chosen to address FPGA resource connections to I/O logic and clock resources per ECP5 and ECP5-5G High-Speed I/O Interface (TN1265).			
6.2	Shared general purpose I/Os are used as inputs for FPGA PLL and Clock inputs.			
7	JTAG			
7.1	Pull-down on TCK. See Table 3.1 on page 7.			
7.2	Pull-up on TDI, TMS, TDO. See Table 3.1 on page 7.			
8	LPDDR3 and DDR3 Interface Requirements			
8.1	DQ, DM, and DQS signals should be routed in a data group and should have similar routing and matched via counts. Using more than three vias is not recommended in the route between the FPGA controller and memory device.			
8.2	Maintain a maximum of ±50 mil between any DQ/DM and its associated DQS strobe within a DQ group. Use careful serpentine routing to meet this requirement.			
8.3	All data groups must reference a ground plane within the stack-up.			
8.4	DDR trace reference must be solid without slots or breaks. It should be continuous between the FPGA and the memory.			
8.5	Provide a separation of 3 W spacing between a data group and any other unrelated signals to avoid crosstalk issues. Use a minimum of 2 W spacing between all DDR traces excluding differential CK and DQS signals. (W is the minimum width of the signal trace allowed)			
8.6	Assigned FPGA I/O within a data group can be swapped to allow clean layout. Do not swap DQS assignments.			
8.7	Differential pair of DQS to DQS_N trace lengths should be matched at ±10 mil.			
8.8	Resistor terminations (DQ) placed in a fly-by fashion at the FPGA is highly recommended. Stub fashion terminations, if used, should not include a stub longer than 600 mil.			
8.9	LDQS/LDQS_N and UDQS/UDQS_N trace lengths should be matched within ±100 mil.			
8.10	Address/control signals and the associated CK and CK_N differential FPGA clock should be routed with a control trace matching ±100 mil.			
8.11	CK to CK_N trace lengths must be matched to within ±10 mil.			
8.12	Address and control signals can be referenced to a power plane if a ground plane is not available. Ground reference is preferred.			
8.13	Address and control signals should be kept on a different routing layer from DQ, DQS, and DM to isolate crosstalk between the signals.			
8.14	Differential terminations used by the CLK/CLKN pair must be located as close as possible to the memory.			
8.15	Address and control terminations placed after the memory component using a fly-by technique are highly recommended. Stub fashion terminations, if used, should not include a stub longer than 600 mils.			



Technical Support Assistance

Submit a technical support case through www.latticesemi.com/techsupport.



Revision History

Date Version		Change Summary		
August 2017	1.4	Updated Table 3.2. Pull-up/Pull-down Recommendations for Configuration Pins. Corrected MCLK/CCLK, CFG pull-up/pull-down values. Added CSSPIN pull-up recommendation.		
		Removed copyright page.		
June 2017	1.3	Changed document number from TN1269 to FPGA-TN-02038. Updated document template. Updated Table 2.1. ECP5 and ECP5-5G FPGA Power Supplies changing CFG[0:2] to CFG[2:0]. Updated Table 3.1. JTAG Pin Recommendations correcting the value in Dedicated CFG[2:0] SSPI Configuration Mode to 001. Update the Power Supplies section to correct Serdes power supply requirements. Added more details to the LFE5U to LFE5UM/LFE5UM5G and LFE5UM to LFE5UM5G Migration section. Changed reference to data sheet from DS1044 to FPGA-DS-02012. Clarify descriptions on various sections.		
December 2015	1.2	Updated Power Supplies section. Revised Voltage (Nominal Value) for V _{CCA} , V _{CCHRX} and V _{CCHTX} in Table 2.1. ECP5 and ECP5-5G FPGA Power Supplies. Updated LFE5U to LFE5UM/LFE5UM5G and LFE5UM to LFE5UM5G Migration section. Changed section title. Removed instances of LFE5U5G. Added new paragraph content. Revised items 1.2, 2.3.1 and 4.2.4 in Table 10.1. Hardware Checklist.		
November 2015	1.1	Added support for ECP5-5G. Changed document title to ECP5 and ECP5-5G Hardware Checklist. Changed ECP5U and ECP5UM to LFE5U and LFE5UM. Updated Configuration Considerations section. Revised PCB recommendation for TDI, TMS and TDO in Table 3.1. JTAG Pin Recommendations. Updated Technical Support Assistance section.		
March 2014	01.0	Initial release.		



7th Floor, 111 SW 5th Avenue Portland, OR 97204, USA T 503.268.8000 www.latticesemi.com