Home

CLASSES

endScript
getBoardId
getBoardVersion
getFirmwareVersion
onKeyboardPress
setDebugMode
wait

console

append clear error overwrite print remove setVerbose warning

files

appendTextFile newLogEntry newLogFile newTextFile

output

ramp set steps steps2

sensors

averageResultsArray read readOhm setMotorPoles setSafetyLimit tareCurrent tareLoadCells

udp

ab2str init onReceive send str2ab

GLOBAL

files

rcb. files

new files()

File interface functions

Source: rcbApi.js, line 1210

Methods

(static) appendTextFile(text, callbackopt)

Appends new text to the created text file. Generates an error if the function newTextFile was never called.

Parameters:

Name	Туре	Attributes	Description
text	String		The raw text to append to the file.
callback	textSaved	<optional></optional>	The function to execute when recording is done.

Source: rcbApi.js, line 1354

(static) newLogEntry(readings, callbackopt, additionalValuesopt)

Records a new entry to the created log file. Generates an error if the function newLogFile was never called.

Parameters:

Name	Туре	Attributes	Description
readings	Object		Sensor readings as returned by the readSensors function.
callback	newLogSaved	<optional></optional>	The function to execute when recording is done.
additionalValues	Array. <(number string)>	<optional></optional>	Additional values to append to the entry.

Source: rcbApi.js, line 1298

(static) newLogFile(paramsopt)

Creates a new file for logging (in the user's working directory). Generates an error if user's working directory is not set.

Parameters:

Home

CLASSES

```
rcb
  endScript
  getBoardId
  getBoardVersion
  getFirmwareVersion
  onKeyboardPress
  setDebugMode
  wait
console
  append
  clear
  error
  overwrite
  print
  remove
  setVerbose
  warning
files
  appendTextFile
  newLogEntry
  newLogFile
  newTextFile
output
  ramp
  set
  steps
  steps2
sensors
  averageResultsArray
  read
  readOhm
  setMotorPoles
  setSafetyLimit
  tareCurrent
  tareLoadCells
udp
   ab2str
  init
  onReceive
```

GLOBAL

send

str2ab

Name	Type	Attributes	Description					
params	Object	<optional></optional>	parameters for file creation. Properties					
			Name	Туре	Attributes	Default	Description	
			prefix	string	<optional></optional>	"Auto"	A prefix to append in front of the file.	
			additionalHeaders	Array. <string></string>	<optional></optional>		Additional header(s) in addition to the standard headers.	

Source: rcbApi.js, line 1278

Examples

```
//Example script recording 5 rows in a loop
var numberOflines = 5;

//Create a new Log
rcb.files.newLogFile({prefix: "Example1"});

//Start the sequence
readSensor();

function readSensor(){
   if(numberOflines>0){
      rcb.sensors.read(readDone);
      numberOflines--;
   }else
      rcb.endScript();
}

function readDone(result){
   rcb.files.newLogEntry(result,readSensor);
}
```

```
//Example recording with extra data
var numberOfLines = 5;
//Create a new log
var add = ["Remaining", "Line"];
rcb.files.newLogFile({prefix: "Example2", additionalHeaders: add});
//Start the sequence
readSensor();
function readSensor(){
   if(numberOfLines>0){
        rcb.sensors.read(readDone);
        numberOfLines--;
   }else
        rcb.endScript();
}
function readDone(result){
   var add = [numberOfLines, 5-numberOfLines];
   rcb.files.newLogEntry(result,readSensor,add);
```

Home

CLASSES

```
rcb
endScript
getBoardId
getBoardVersion
getFirmwareVersion
onKeyboardPress
setDebugMode
wait

console
append
clear
error
overwrite
print
```

files

remove setVerbose

warning

appendTextFile newLogEntry newLogFile newTextFile

output

ramp set steps steps2

sensors

averageResultsArray read readOhm setMotorPoles setSafetyLimit tareCurrent tareLoadCells

udp

ab2str init onReceive send str2ab

GLOBAL

```
//This example continuously records data at full
//speed until the user stops the script

//Create a new log
rcb.files.newLogFile({prefix: "Continuous"});

//Start the sequence
readSensor();

function readSensor(){
    rcb.sensors.read(saveResult,10);
}

function saveResult(result){
    rcb.files.newLogEntry(result, readSensor);
}
```

(static) newTextFile(paramsopt)

Creates a new empty file for writing raw text (in the user's working directory). Generates an error if user's working directory is not set.

Parameters:

Name	Туре	Attributes	Description				
params Object	Object	<optional></optional>	parameters for file creation. Properties				
		Name	Type	Attributes	Default	Description	
			prefix	string	<optional></optional>	"Auto"	A prefix to append in front of the file.
			extension	string	<optional></optional>	"txt"	Custom file extension.

Source: rcbApi.js, line 1334

Example

```
//Example recording to a raw text file
rcb.files.newTextFile({prefix: "RawTextExample"});
rcb.files.appendTextFile("Plain raw text\r\n", function(){
    rcb.files.appendTextFile("A new line...", function(){
        rcb.files.appendTextFile("same line...", function(){
            rcb.files.appendTextFile("more...", rcb.endScript);
        });
    });
});
```

Documentation generated by JSDoc 3.6.3 on Wed Aug 21 2019 09:49:26 GMT-0400 (Eastern Daylight Time) using the Minami theme.