



PIEP – DeletionPS User Guide





1. VERSIONING AND CONTROL VALIDATION

VERSIONING HISTORY

Version	AUTHOR	REVISION	Date
1.0	RCAS (CGI)	Creation	20/05/2020
1.1	RCAS (CGI)	Review prerequisite	17/08/2020

VALIDATION

Version	Name	Date
1.0		





2. DOCUMENT CONTENT

1.	VERSIONING AND CONTROL VALIDATION	
2.	DOCUMENT CONTENT	. 3
3.	SCRIPT DESCRIPTION	. 4
	3.1 Objective	
	3.2 Prerequisite	. 4
4.	USER GUIDE	. 4 . 4 . 5
	4.1 Prepare the input file	. 5
	4.2 Configure 01-DeletionPS.bat	
	4 3 Run DeletionPS	





3. SCRIPT DESCRIPTION

3.1 Objective

The purpose of DeletionPS is to delete the tags on a PI data archive server.

The user have to provide the server name and the list of tags to delete.

3.2 Prerequisite

- Microsoft Powershell (1.0 or later).
- PI SMT 2018 or later.






4. USER GUIDE

Copy the folder DeletionPS in your local machine/server.

4.1 Prepare the input file

Get the list of the tags you want to delete. Copy the list on the folder ".\input\Points.txt", one tag per line. Example :



4.2 Configure 01-DeletionPS.bat

Edit the file ".\script\01-DeletionPS.bat".

cd ..
powershell.exe -file .\DeletionPS.ps1 -piServerHost "PI-CENTER-HQ"

Modify the following parameters:

• **PIServerHost**: Name of the PI Server to delete tags (exemple: PI-CENTER-HQ)

Then save the modifications and close the file.





4.3 Run DeletionPS

Run the script 01-DeletionPS.bat (do not run it as administrator).

You should have the following window opened. Presse <Enter> to valid the deletion.

Then let the application delete all archived event and tags structure. If some tags does not exist, the application will mention it (example below with tag <test2> which does not exist):

Press <Enter> to quit the application.