$$\begin{array}{c} \downarrow \\ \tau_{load} \\ + \\ - \\ \hline \\ \frac{1}{sI_m + F_m} \end{array} \longrightarrow \omega \longrightarrow$$