
Caveatron Wiring Diagram 12m LIDAR Module (RP) - Rev. A

v. 2019-02-12



*NOTES

- 1. Output voltage of regulator sets LIDAR rotation speed. For approximately 5 Hz rotation speed, the set voltage is 3.68V.
- 2. Numbers designate pin numbers on connector.
- 3. RX and TX as shown at the LIDAR connector are from the perspective of the Arduino Due board.